

[illegible][illegible]

```

LL          IIIII
LL          IIIII
LL          II
LL          II
LL          II
LL          II
LL          II
LL          II
LL          II
LL          II
LL          II
LL          II
LL          II
LL          II
LLLLLLLLLLL IIIII
LLLLLLLLLLL IIIII
SSSSSSSSS
SSSSSSSSS
SS
SS
SS
SS
SSSSSSS
SSSSSSS
SS
SS
SS
SS

```

(1)	62	DECLARATIONS
(1)	200	REGISTER DEFINITIONS
(1)	332	SPEED CONVERSION TABLES
(1)	390	CONTROLLER INITIALIZATION
(1)	440	CONTROLLER INITIALIZATION
(1)	516	UNIT INITIALIZATION
(1)	668	MAINTENANCE ROUTINES
(1)	742	OUTPUT MODEM CONTROL
(1)	783	RECEIVER INTERRUPT SERVICE
(1)	900	START I/O ROUTINE
(1)	994	PORT DMA ROUTINES
(1)	1290	PORT ROUTINES STOP, RESUME, XON, XOFF
(1)	1437	OUTPUT INTERRUPT SERVICE
(1)	1653	SET SPEED, PARITY PARAMETERS



```
0000 1      .TITLE YFDRIVER - Port Driver for DHU/DHV
0000 2      .IDENT 'V04-000'
0000 3
0000 4      *****
0000 5      *
0000 6      *  COPYRIGHT (c) 1978, 1980, 1982, 1984 BY
0000 7      *  DIGITAL EQUIPMENT CORPORATION, MAYNARD, MASSACHUSETTS.
0000 8      *  ALL RIGHTS RESERVED.
0000 9      *
0000 10     *  THIS SOFTWARE IS FURNISHED UNDER A LICENSE AND MAY BE USED AND COPIED
0000 11     *  ONLY IN ACCORDANCE WITH THE TERMS OF SUCH LICENSE AND WITH THE
0000 12     *  INCLUSION OF THE ABOVE COPYRIGHT NOTICE. THIS SOFTWARE OR ANY OTHER
0000 13     *  COPIES THEREOF MAY NOT BE PROVIDED OR OTHERWISE MADE AVAILABLE TO ANY
0000 14     *  OTHER PERSON. NO TITLE TO AND OWNERSHIP OF THE SOFTWARE IS HEREBY
0000 15     *  TRANSFERRED.
0000 16     *
0000 17     *  THE INFORMATION IN THIS SOFTWARE IS SUBJECT TO CHANGE WITHOUT NOTICE
0000 18     *  AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT
0000 19     *  CORPORATION.
0000 20     *
0000 21     *  DIGITAL ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS
0000 22     *  SOFTWARE ON EQUIPMENT WHICH IS NOT SUPPLIED BY DIGITAL.
0000 23     *
0000 24     *
0000 25     *****
0000 26
0000 27     ++
0000 28     FACILITY:
0000 29
0000 30     VAX/VMS TERMINAL DRIVER
0000 31
0000 32     ABSTRACT:
0000 33
0000 34     DHU/DHV ASYNC PORT DRIVER
0000 35
0000 36     AUTHOR:
0000 37
0000 38     RICK SPITZ/ANDREW PALKA
0000 39
0000 40     Revision history:
0000 41
0000 42     V03-004 LMP0275      L. Mark Pilant,      12-Jul-1984 21:05
0000 43     Initialize the ACL info in the ORB to be a null descriptor
0000 44     list rather than an empty queue. This avoids the overhead
0000 45     of locking and unlocking the ACL mutex, only to find out
0000 46     that the ACL was empty.
0000 47
0000 48     V03-003 EMD0097      Ellen M. Dusseault    30-Apr-1984
0000 49     Fix a few bugs - device timeout problem and test the
0000 50     abort flag first to see if it is necessary to clear it.
0000 51     Also add DEV$M_NNM characteristic to DEVCHAR2 so that
0000 52     these devices will have the prefix "node$".
0000 53
0000 54     V03-002 TMH0002      Tim Halvorsen         14-Apr-1984
0000 55     Fix references to UCBSL_OWNUIC and UCBSW_VPROT to use ORB.
0000 56
0000 57     V03-001 EMD0070      Ellen M. Dusseault    30-MAR-1984
```

YFDRIIVER  
V04-000

- Port Driver for DHU/DHV

M 5

16-SEP-1984 02:26:48 VAX/VMS Macro V04-00  
5-SEP-1984 04:17:43 [TTDRVR.SRC]YFDRIIVER.MAR;1

Page 2  
(1)

0000 58 :  
0000 59 :  
0000 60 :--

Modify to make code more efficient.

YFDI  
V04-

```
0000 62      .SBTTL  DECLARATIONS
0000 63
0000 64      :
0000 65      : EXTERNAL DEFINITIONS:
0000 66      :
0000 67      $PRDEF
0000 68      $ACBDEF      : DEFINE ACB
0000 69      $CRBDEF      : DEFINE CRB
0000 70      $DCDEF      : DEFINE ADAPTER TYPES
0000 71      $DDBDEF      : DEFINE DDB
0000 72      $DEVDEF      : DEFINE DEVICE TYPES
0000 73      $DYNDEF      : DEFINE DYNAMIC STRUCTURE TYPES
0000 74      $IDBDEF      : DEFINE IDB OFFSETS
0000 75      $IODEF      : DEFINE I/O FUNCTION CODES
0000 76      $IRPDEF      : DEFINE IRP
0000 77      $ORBDEF      : DEFINE OBJECT RIGHTS BLOCK
0000 78      $SSDEF      : DEFINE SYSTEM STATUS CODES
0000 79      $TTYDEF      : DEFINE TERMINAL DRIVER SYMBOLS
0000 80      $TTDEF      : DEFINE TERMINAL TYPES
0000 81      $TT2DEF      : DEFINE EXTENDED CHARACTERISTICS
0000 82      $TQDEF      : DEFINE TIMER QUEUE OFFSETS
0000 83      $UCBDEF      : DEFINE UCB
0000 84      $UBADEF      : DEFINE UBA
0000 85      $VECDEF      : DEFINE VECTOR FOR CRB
0000 86      $TTYMACS      : DEFINE TERMINAL DRIVER MACROS
0000 87      $TTYDEFS      : DEFINE TERMINAL DRIVER SYMBOLS
0000 88      $TTYMODEM      : DEFINE MODEM DEFINITIONS
0000 89
0000 90
0000 91
0000 92      :
0000 93      : LOCAL STORAGE
0000 94      :
0000 95      .PSECT $$$105_PROLOGUE
0000 96
0000 97      :
0000 98      : Driver prologue table:
0000 99      :
0000 100
0000 101      :
0000 102      : Note. The DPT says that this driver has a UBA adapter type.
0000 103      : In fact it will work with a Q-bus VAX, either mapped or unmapped
0000 104      :
0000 105      YFSDPT::
0000 106      DPTAB      -      : DRIVER START
0000 107      END=YFSEND,-      : DRIVER PROLOGUE TABLE
0000 108      UCBSIZE=UCB$C TT LENGTH+4,- : End and offset to INIT's vectors
0000 109      FLAGS=DPT$M_NOUNLOAD,-      : SIZE OF UCB
0000 110      ADAPTER=UBA,-      : NO UNLOAD ALLOWED
0000 111      MAXUNITS=16,-      : ADAPTER TYPE
0000 112      DEFUNITS=16,-      : Number of units to create
0000 113      NAME=YFDRIVER,-      : Number of units to create
0000 114      VECTOR=PORT VECTOR,-      : NAME OF DRIVER
0000 115      DELIVER=YF$DELIVER      : PORT DRIVER VECTOR TABLE
0000 116      DPT_STORE INIT      : Unit delivery routine
0000 117      DPT_STORE UCB,UCB$B_FIPL,B,8 : FORK IPL
0000 118      DPT_STORE UCB,UCB$L_DEVCHAR,L,<- : CHARACTERISTICS
```



```
003C 119 DEVSM_REC!- ;
003C 120 DEVSM_AVL!- ;
003C 121 DEVSM_IDV!- ;
003C 122 DEVSM_ODV!- ;
003C 123 DEVSM_TRM!- ;
003C 124 DEVSM_CCL>
0043 125 DPT_STORE UCB,UCBSL_DEVCHAR2,L,- ; DEVICE CHARACTERISTICS
0043 126 <DEVSM_NNM> ; PREFIX WITH 'NODES'
004A 127 DPT_STORE UCB,UCBSB_DEVCLASS,B,DC$ TERM;
004E 128 DPT_STORE UCB,UCBSB_TT_DETYPE,B,TT$ UNKNOWN ; TYPE
0052 129 DPT_STORE UCB,UCBSW_TT_DESIZE,BW,TTY$GW_DEFBUF ; BUFFER SIZE
0059 130 DPT_STORE UCB,UCBSL_TT_DECHAR,BL,TTY$GL_DEFCHAR ; DEFAULT CHARACTERS
0060 131 DPT_STORE UCB,UCBSL_TT_DECHA1,BL,TTY$GL_DEFCHAR2 ; DEFAULT CHARACTERS
0067 132 DPT_STORE UCB,UCBSW_TT_DESPEE,BB,TTY$GB_DEFSPEED ; DEFAULT SPEED
006E 133 DPT_STORE UCB,UCBSW_TT_DESPEE+1,BB,TTY$GB_RSPEED ; DEFAULT RSPEED
0075 134 DPT_STORE UCB,UCBSB_TT_DEPARI,BB,TTY$GB_PARITY ; DEFAULT PARITY
007C 135 DPT_STORE UCB,UCBSB_DEVTYPE,B,TT$ UNKNOWN ; TYPE
0080 136 DPT_STORE UCB,UCBSW_DEVBUFSIZ,BW,TTY$GW_DEFBUF ; BUFFER SIZE
0087 137 DPT_STORE UCB,UCBSL_DEVDEPEND,BL,TTY$GL_DEFCHAR ; DEFAULT CHARACTERS
008E 138 DPT_STORE UCB,UCBSL_DEVDEPN2,BL,TTY$GL_DEFCHAR2 ; DEFAULT CHARACTERS
0095 139 DPT_STORE UCB,UCBSW_TT_SPEED,BB,TTY$GB_DEFSPEED ; DEFAULT SPEED
009C 140 DPT_STORE UCB,UCBSW_TT_SPEED+1,BB,TTY$GB_RSPEED ; DEFAULT RSPEED
00A3 141 DPT_STORE UCB,UCBSB_DIPL,B,21 ; DEVICE IPL
00A7 142 DPT_STORE UCB,UCBSL_TT_WFLINK,L,0 ; Zero write queue.
00AE 143 DPT_STORE UCB,UCBSL_TT_WBLINK,L,0 ; Zero write queue.
00B5 144 DPT_STORE UCB,UCBSL_TT_RTIMOU,L,0 ; Zero read timed out disp.
00BC 145 DPT_STORE ORB,ORBSB_FLAGS,B,- ; Protection block flags
00BC 146 2ORBSM_PROT 16> ; SOGW protection word
00C0 147 DPT_STORE ORB,ORBSW_PROT,BW,TTY$GW_PROT ; Default allocation protect
00C7 148 DPT_STORE ORB,ORBSL_OWNER,BL,TTY$GL_OWNUIC ; Default owner UIC
00CE 149 DPT_STORE DDB,DDBSL_DDT,D,YF$DDT
00D3 150 DPT_STORE REINIT
00D3 151 DPT_STORE CRB,CRBSL_INTD+4,D,YF$INTINP ; RECEIVER INTERRUPT
00D8 152 DPT_STORE CRB,CRBSL_INTD2+4,D,YF$INTOUT ; TRANSMITTER INTERRUPT
00DD 153 DPT_STORE CRB,CRBSL_INTD+VECSL_INITIAL,D,YF$INITIAL ; CONTROLLER INIT
00E2 154 DPT_STORE CRB,CRBSL_INTD+VECSL_UNITINIT,D,YF$INITLINE ; UNIT INIT
00E7 155
00E7 156 DPT_STORE END
0000 157
0000 158 DDTAB DEVNAM = YF,- ; DUMMY DHU PORT DRIVER DISPATCH TABLE
0000 159 START = 0,-
0000 160 FUNCTB = 0
00000038 161 .PSECT $$$115_DRIVER, LONG
0038 162
0038 163 :
0038 164 : THE ASSOCIATED CLASS DRIVER USES THIS TABLE TO COMMAND THE PORT DRIVER.
0038 165 : THE ADDRESS OF THIS TABLE IS CONTAINED IN THE TERMINAL UCB EXTENSION AREA.
0038 166 : THE OFFSET DEFINITIONS ARE DEFINED BY TTYDEFS.
0038 167 :
00000000 0038 168 YF$SL_SIL_ERROR::
0038 169 .LONG 0 ; Indicates Silo not empty at interrupt
00000000 003C 170 YF$SL_ERROR::
0040 171 .LONG 0 ; Indicates DMA count non zero at
0040 172 ; interrupt
00000000 0040 173 YF$SL_DMAXMT_ERROR::
0040 174 .LONG 0 ; Indicates DMA error bit set by DHU
0044 175 YF$SL_INACT_ERROR::
```

```
00000000 0044 176 .LONG 0 ; Indicates UCBSM_INT clear at interrupt
          0048 177 PORT_VECTOR:
          0048 178
          0048 179 ;
          0048 180 ; DHU/DHV SPECIFIC DISPATCH TABLE
          0048 181 ;
          0048 182 $VECINI YF,YF$NULL
          0080 183 $VEC STARTIO,YF$STARTIO ; START NEW OUTPUT
          004C 184 $VEC SET_LINE,YF$SET_LINE ; SET NEW SPEED/PARITY
          0054 185 $VEC DS_SET,YF$DS_SET ; SET OUTPUT MODEM SIGNALS
          0058 186 $VEC XON,YF$XON ; SEND XON SEQUENCE
          005C 187 $VEC XOFF,YF$XOFF ; SEND XOFF SEQUENCE
          0060 188 $VEC STOP,YF$STOP ; STOP OUTPUT
          0064 189 $VEC ABORT,YF$ABORT ; ABORT OUTPUT IN PROGRESS
          006C 190 $VEC RESUME,YF$RESUME ; RESUME STOPPED OUTPUT
          0070 191 $VEC MAINT,YF$MAINT ; INVOKE MAINTENANCE FUNCTION
          007C 192 $VEC FORKRET,YF$FORK ; PORT FORK CALLBACK
          0080 193 $VECEND
          0084 194
          0084 195 ;
          0084 196 YF$NULL: ; NULL PORT ROUTINE
05 0084 197 RSB
     0085 198
```



```
0085 200 .SBTTL REGISTER DEFINITIONS
0085 201
0085 202
00000000 0085 203 DHUCSR = 0 ; Base CSR
00000002 0085 204 DHURBF = 2 ; Received data fifo
00000002 0085 205 DHUTXC = 2 ; DHV single char register
00000002 0085 206 DHUTCX = 2 ; DHU timer control
00000004 0085 207 DHULPR = 4 ; Line parameters
00000006 0085 208 DHUTXF = 6 ; Transmit FIFO
00000006 0085 209 DHUTFS = 6 ; Transmit FIFO size
00000007 0085 210 DHUSTT = 7 ; Modem status
00000008 0085 211 DHULCT = 8 ; Line control
0000000A 0085 212 DHUTBF1 = 10 ; low bits of address
0000000C 0085 213 DHUTBF2 = 12 ; High bits of address
0000000E 0085 214 DHUTCT = 14 ; Byte count
0085 215
0085 216
0085 217 : CSR BIT DEFINITIONS ( CSR ) ( READ/WRITE )
0085 218 : (NOTE: THIS REGISTER MUST ONLY BE READ IN RESPONSE TO A TRANSMIT INTERRUPT.
0085 219 : TO LOAD AN INDIRECT REGISTER, ONLY WRITE OPERATIONS MAY BE USED.
0085 220 : READ-MODIFY-WRITE OPERATIONS MUST NEVER BE USED)
0085 221
0085 222 $YIELD DHUCSR,0,<-
0085 223 <IADDR,4,M>,- ; INDIRECT REGISTER ADDRESS
0085 224 <1>,- ; DON'T USE THIS BIT
0085 225 <CLEAR,1,M>,- ; MASTER RESET
0085 226 <RCVINT,1,M>,- ; RECEIVER INTERRUPT ENABLE
0085 227 <1>,- ; DON'T USE THIS BIT
0085 228 <LINE,4,M>,- ; LINE NUMBER (0 - 15)
0085 229 <DMAERR,1,M>,- ; DMA error
0085 230 <DIGFAL,1,M>,- ; Diagnostic failed
0085 231 <SNDINT,1,M>,- ; TRANSMIT INTERRUPT ENABLE
0085 232 <SNDRDY,1,M>,- ; TRANSMITTER READY
0085 233 >
0085 234
0085 235 : RECEIVER BUFFER ( CSR+2 ) ( READ ONLY )
0085 236
0085 237 $YIELD DHURCV,0,<-
0085 238 <BUF,8,M>,- ; RECEIVER DATA
0085 239 <LINE,4,M>,- ; LINE NUMBER (0 - 7)
0085 240 <PARERR,1,M>,- ; PARITY ERROR
0085 241 <FRAMER,1,M>,- ; FRAME ERROR
0085 242 <OVERRUN,1,M>,- ; OVERRUN ERROR
0085 243 <VALID,1,M>,- ; DATA VALID
0085 244 >
0085 245
0085 246 : LINE PARAMETER REGISTER ( CSR+4 , Indirect register)
0085 247
0085 248
0085 249 $YIELD DHULPR,0,<-
0085 250 <1>,- ; DON'T USE THIS BIT
0085 251 <DIAG1,1,M>,- ; Diagnostics control
0085 252 <DIAG2,1,M>,- ; Diagnostics control
0085 253 <SIZE,2,M>,- ; CHARACTER SIZE
0085 254 <PARITY,1,M>,- ; PARITY ENABLE
0085 255 <ODD,1,M>,- ; ODD PARITY
0085 256 <STOP,1,M>,- ; NUMBER STOP BITS
```

```
0085 257 <RSPEED,4,M>,- : RECEIVER LINE SPEED
0085 258 <TSPEED,4,M>,- : TRANSMITTER LINE SPEED (BOTH RVC/TX FOR LINES 2-7)
0085 259 >
0085 260 :
0085 261 : LINE CONTROL INDIRECT REGISTER (CSR + 8, Indirect register)
0085 262 :
0085 263 :
0085 264 $VIELD DHULCT,0,<-
0085 265 <ABORT,1,M>,- : Output abort
0085 266 <DAUTO,1,M>,- : AUTO XON/OFF
0085 267 <RCV,1,M>,- : RECEIVER ENABLE
0085 268 <BREAK,1,M>,- : SEND BREAK
0085 269 <IAUTO,1,M>,- : Incoming Auto flow enable
0085 270 <SNDOFF,1,M>,- : Send XOFF
0085 271 <MAINT,2,M>,- : Maintenance
0085 272 <MODEM,1,M>,- : Modem control line
0085 273 <DTR,1,M>,- : Data terminal ready
0085 274 <2>,-
0085 275 <RTS,1,M>,- : Request to send
0085 276 >
0085 277 :
0085 278 : Status register
0085 279 $VIELD DHUSTT,0,<-
0085 280 <3>,-
0085 281 <CTS,1,M>,-
0085 282 <DCD,1,M>,-
0085 283 <RI,1,M>,-
0085 284 <1>,-
0085 285 <DSR,1,M>,-
0085 286 >
0085 287 :
0085 288 : Constant value for Base CSR
0085 289 : Enables both receive and transmit interrupts
0085 290
00004040 0085 291 DHUCSR$C_BASE = <DHUCSR$M_RCVINT!DHUCSR$M_SNDINT>
0085 292 :
0085 293 : MACRO USED TO ACCESS INDIRECT REGISTERS
0085 294 :
0085 295 :
0085 296 .MACRO SETIND REG
0085 297 .IF B, REG
0085 298 MOVL UCBSL CRB(R5),R0 : GET CRB ADDRESS
0085 299 MOVL @CRB$C_INTD+VEC$C_IDB(R0),R0 : GET CSR ADDRESS
0085 300 BISW3 #<DHUCSR$C_BASE>,-
0085 301 UCBSW_UNIT(R5),DHUCSR(R0); SELECT INDIRECT FIELD
0085 302 .IFF
0085 303 BISW3 #<DHUCSR$C_BASE>,-
0085 304 UCBSW_UNIT(R5),DHUCSR(REG); SELECT INDIRECT FIELD
0085 305 .ENDC
0085 306 .ENDM SETIND
0085 307 :
0085 308 :
0085 309 : Extra field in UCB
0085 310 : This field could be removed if 2 spare bits can be found in the UCB for
0085 311 : the use of the port driver. (This would save 4 bytes from the declared length
0085 312 : of the UCB)
0085 313
```

```
00000134 0085 314 UCBSB_DHUFLG = UCBSB_TT_LENGTH ; Allocate at end of previous ucb
0085 315
0085 316 $VIELD UCB_0 <-
0085 317 <MAP,1,M>,- ; Map registers available if 1
0085 318 <DHU,1,M>,- ; DHU if 1, DHV if 0
0085 319 <XOFF,1,M>,- ; XOFF if 1, XON if 0
0085 320 >
0085 321
0085 322 ::
0085 323 ::
0085 324
0085 325 .MACRO DELAY
0085 326 .REPEAT 3
0085 327 NOP
0085 328 .ENDR
0085 329 .ENDM
0085 330
```



```
0085 332 .sbttl SPEED CONVERSION TABLES
0085 333
0085 334
0085 335 :: macro to generate table of acceptable speeds for DHU/DHV
0085 336 ::
0085 337 .MACRO SPD CONV BAUD
0085 338 .=$YF$VMS_$SPEEDS+$TT$C_'BAUD'
0085 339 .byte $DHU$SPD$C_'BAUD'
0085 340 .=$YF$DHU_$SPEEDS+$DHU$SPD$C_'BAUD'
0085 341 .byte $TT$C_'BAUD'
0085 342 .ENDM
0085 343
0085 344 ::
0085 345 :: speed values recognized by the DHU/DHV
0085 346 ::
00000000 0085 347 DHUSPD$C_BAUD_50=0
00000001 0085 348 DHUSPD$C_BAUD_75=1
00000002 0085 349 DHUSPD$C_BAUD_110=2
00000003 0085 350 DHUSPD$C_BAUD_134=3
00000004 0085 351 DHUSPD$C_BAUD_150=4
00000005 0085 352 DHUSPD$C_BAUD_300=5
00000006 0085 353 DHUSPD$C_BAUD_600=6
00000007 0085 354 DHUSPD$C_BAUD_1200=7
00000008 0085 355 DHUSPD$C_BAUD_1800=8
00000009 0085 356 DHUSPD$C_BAUD_2000=9
0000000A 0085 357 DHUSPD$C_BAUD_2400=10
0000000B 0085 358 DHUSPD$C_BAUD_4800=11
0000000C 0085 359 DHUSPD$C_BAUD_7200=12
0000000D 0085 360 DHUSPD$C_BAUD_9600=13
0000000E 0085 361 DHUSPD$C_BAUD_19200=14
0000000F 0085 362 DHUSPD$C_BAUD_38400=15
0085 363
0085 364 ; Allocate and initialize table of speed values
0085 365 YF$VMS_$SPEEDS:
0085 366 .REPEAT 16
0085 367 .BYTE -1 ; Initial to illegal value
FF 0085 368 .ENDR
0095 369 YF$DHU_$SPEEDS:
0095 370 .REPEAT 16
0095 371 .BYTE 0 ; Initial to zero
00 0095 372 .ENDR
00A5 373
00A5 374 ; Now build up the table of acceptable speed values
00A5 375
00A5 376 SPD CONV BAUD_75
0097 377 SPD CONV BAUD_110
0098 378 SPD CONV BAUD_134
0099 379 SPD CONV BAUD_150
009A 380 SPD CONV BAUD_300
009B 381 SPD CONV BAUD_600
009C 382 SPD CONV BAUD_1200
009D 383 SPD CONV BAUD_1800
009E 384 SPD CONV BAUD_2000
009F 385 SPD CONV BAUD_2400
00A0 386 SPD CONV BAUD_4800
00A1 387 SPD CONV BAUD_9600
00A3 388 SPD CONV BAUD_19200
```

```
00A4 390 .SBTTL CONTROLLER INITIALIZATION
00A4 391
00A4 392
00A4 393
00A4 394 :++
00A4 395 YF$DELIVER - Unit delivery routine
00A4 396
00A4 397 FUNCTIONAL DESCRIPTION:
00A4 398
00A4 399 THIS ROUTINE IS ENTERED AT SYSTEM STARTUP
00A4 400
00A4 401 It checks the device to see if the specified unit number exists.
00A4 402 This is necessary as the DHV has 8 lines, while the DHU has 16
00A4 403
00A4 404 INPUTS:
00A4 405
00A4 406 R4 = ADDRESS OF THE CONTROLLER CSR
00A4 407 R5 = Unit number
00A4 408
00A4 409 OUTPUTS:
00A4 410
00A4 411 R0 = 1 if unit exists
00A4 412 = 0 if unit does not exist
00A4 413
00A4 414 IMPLICIT INPUTS:
00A4 415
00A4 416
00A4 417 :--
00A4 418 YF$DELIVER::
10 55 D1 00A4 419 CMPL R5,#16
50 1C 18 00A7 420 BGEQ 10$ : exit if unit too large
15 50 64 B0 00A9 421 MOVW (R4),R0 : Read base CSR
11 50 05 E0 00AC 422 BBS #DHUCSR$V_CLEAR,R0,10$ : controller bad
50 0D E0 00B0 423 BBS #DHUCSR$V_DIGFAL,R0,10$ : controller bad
00B4 424 :
00B4 425 : Note. If controller has not passed self test then we cannot rely on
00B4 426 : the value read from DHUSTT
00B4 427
50 07 A4 90 00B4 428 MOVW DHUSTT(R4),R0 : get status byte
05 50 E8 00B8 429 BLBS R0,5$ : low bit indicates DHU
08 55 D1 00BB 430 CMPL R5,#8 : DHV has only 8 lines
05 18 00BE 431 BGEQ 10$
00C0 432 5$:
50 01 D0 00C0 433 MOVL #1,R0 : unit exists
02 11 00C3 434 BRB 20$
00C5 435 10$:
50 05 D4 00C5 436 CLRL R0 : unit does not exist
00C7 437 20$:
05 00C7 438 RSB
```

```
00C8 440          .SBTTL  CONTROLLER INITIALIZATION
00C8 441
00C8 442
00C8 443
00C8 444      **
00C8 445      YFSINITIAL - INITIALIZE INTERFACE
00C8 446
00C8 447      FUNCTIONAL DESCRIPTION:
00C8 448
00C8 449      THIS ROUTINE IS ENTERED AT SYSTEM STARTUP AND POWER RECOVERY.
00C8 450
00C8 451      INPUTS:
00C8 452
00C8 453          R4 = ADDRESS OF THE UNIT CSR
00C8 454          R5 = IDB OF UNIT
00C8 455          R8 = ADDRESS OF THE UNIT CRB
00C8 456
00C8 457      OUTPUTS:
00C8 458
00C8 459          R2 is destroyed.
00C8 460
00C8 461      IMPLICIT INPUTS:
00C8 462
00C8 463          IPL = IPL$ POWER
00C8 464
00C8 465      --
00C8 466      YFSINITIAL::                                ; INITIALIZE DHU UNIT
00C8 467
00C8 468      SET UP CONTROLLER
00C8 469
00C8 470          CLASS_CTRL_INIT YFS$DPT,PORT_VECTOR; RELOCATE THE NECESSARY TABLES
00F5 471 25$:
00F5 472
00F5 473      Note. The DHV takes about 2 seconds to initialise
00F5 474      and the DHU up to 5
00F5 475      so we assume that initialization has taken place
00F5 476      We could start the initialization and then do a 'skip self test'
00F5 477      operation to bring the self test time down to a few milliseconds,
00F5 478      however we would not then know if the board was good or not.
00F5 479
00F5 480
00F5 481          BITW    #DHUCSR$M_CLEAR,(R4)
00F8 482          BNEQ    26$                                ; dont do reset if still there
00FA 483          MOVW    #DHUCSR$M_CLEAR,(R4)                ; CONTROLLER RESET
00FD 484 26$:
00FD 485
00FD 486          WAIT TILL CONTROLLER INITIALIZATION IS COMPLETE
00FD 487
00FD 488          5 second wait here !!!
00FD 489
00FD 490          TIMEWAIT    #500000,#DHUCSR$M_CLEAR,(R4),W,.FALSE.
0124 491
0124 492
0124 493          BLBC     R0,YFS$CTRL_ERROR
0127 494          BITW    #DHUCSR$M_DIFGAL,(R4)
012C 495          BEQL     90$
012E 496          MOVW    #0,R0                                ; failed self test, dont use
```

64 20 B3 00F5 481  
64 03 12 00F8 482  
64 20 B0 00FA 483  
2E 50 E9 0124 493  
64 2000 8F B3 0127 494  
50 00 B0 012C 495  
50 00 B0 012E 496



```

      22 11 0131 497 BRB YF$CTRL_ERROR
      64 4040 BF 80 0133 498 90$:
      0133 499 MOVW #DHUCSR$C_BASE,(R4) ; set up base csr value
      0138 500
      0138 501
      0138 502 100$:
      0B A8 46 8F 90 0138 503 MOVB #DTS_DHV,CB$B_TT_TYPE(R8) ; CONTROLLER IS DHV
      50 07 A4 90 013D 504 MOVB DHUSTT(R4),R0 ; test for DHU or DHV
      0D 50 E9 0141 505 BLBC R0,110$ ; DHV does not have silo timeout
02 A4 00000000 GF 90 0144 506 MOVB G^TTYSGB_SILOTIME,DHUTCR(R4) ; INIT INPUT SILO TIMEOUT VALUE
      0B A8 47 8F 90 014C 507 MOVB #DTS_DHV,CB$B_TT_TYPE(R8) ; CONTROLLER IS DHU
      50 01 D0 0151 508 110$:
      05 05 0154 509 MOVL #SS$_NORMAL,R0
      0155 510 RSB
      0155 511
      05 0155 512 YF$CTRL_ERROR:
      0156 513 RSB
      0156 514
```

```
0156 516 .SBTTL UNIT INITIALIZATION
0156 517
0156 518 : YFSINITLINE - UNIT INITIALIZATION
0156 519 :
0156 520 FUNCTIONAL DESCRIPTION:
0156 521 :
0156 522 THIS ROUTINE PERFORMS A SIMPLE UNIT INITIALIZATION.
0156 523 :
0156 524 INPUTS:
0156 525 :
0156 526 R5 = UCB ADDRESS
0156 527 :
0156 528 OUTPUTS:
0156 529 :
0156 530 R4,R5 ARE PRESERVED.
0156 531 :--
0156 532
0156 533 YFSINITLINE::
0156 534 MOVAL YF$VEC,R0 ; GET THE DISPATCH TABLE ADDRESS
0156 535 CLASS_UNIT_INIT
0156 536 BISW #UCB$M_ONLINE,UCB$W_STS(R5); SET ONLINE
0156 537
0156 538 ASHL UCB$W_UNIT(R5),#1,R3 ; BUILD UNIT'S BIT MASK
0156 539 MOVW R3,UCB$W_TT_UNITBIT(R5) ; SAVE IT
0156 540 MOVW GATTY$GB_PARITY,UCB$B_TT_PARITY(R5) ; STORE TERMINAL'S PARITY VALUE IN UCB
0156 541 :
0156 542 BISW #TTY$M_PC_DMAAVL!TTY$M_PC_XOFAVL,-; SHOW DMA FEATURE AVAILABLE FOR U
0156 543 UCB$W_TT_PRTCTL(R5) ; IN PORT LEVEL
0156 544
0156 545 MOVL UCB$L_TT_CLASS(R5),R1 ; ADDRESS CLASS VECTOR TABLE
0156 546 JSB @CLASS_SETUP_UCB(R1) ; INIT UCB FIELDS
0156 547
0156 548 :
0156 549 : Perform check to see if device is good
0156 550 :
0156 551 :
0156 552 PUSHF #M<R4,R5>
0156 553 MOVL UCB$L_CRB(R5),R4 ; GET CRB ADDRESS
0156 554 MOVL @CRB$C_INTD+VEC$L_IDB(R4),R4 ; GET CSR ADDRESS
0156 555 MOVZWL UCB$W_UNIT(R5),R5
0156 556 JSB YF$DECIVER ; test this device is ok
0156 557 POPR #M<R4,R5>
0156 558 BLBS R0,11$
0156 559 :
0156 560 : DHU is in a bad way, set device offline
0156 561 :
0156 562 BISW #UCB$M_ONLINE,UCB$W_STS(R5); SET OFFLINE
0156 563 11$:
0156 564 : Test to see the type of configuration
0156 565 :
0156 566 CLRB UCB$B_DHUFLG(R5)
0156 567 SETIND
0156 568 BISB #UCB$M_DHU,UCB$B_DHUFLG(R5); Assume DHU
0156 569 MOVW DHUSTT(R0),R0 ; test if DHU or DHV
0156 570 BLBS R0,12$
0156 571 :
0156 572 : Note. The DHV always interrupts at BR4
0156 573 : This becomes IPL 20 on a VAX
```

50 FEE CF DE 0156 534  
64 A5 10 A8 0156 535  
53 01 54 A5 78 0156 536  
0106 C5 53 B0 0156 537  
00F8 C5 00000000 GF 90 0156 538  
0122 C5 A8 0156 539  
51 0114 C5 D0 0156 540  
08 B1 16 0156 541  
0156 542  
0156 543  
0156 544  
0156 545  
0156 546  
0156 547  
0156 548  
0156 549  
0156 550  
54 24 A5 D0 0156 551  
54 2C B4 D0 0156 552  
55 54 A5 3C 0156 553  
FECA CF 16 0156 554  
04 50 BA 0156 555  
0156 556  
0156 557  
0156 558  
0156 559  
64 A5 10 AA 0156 560  
0156 561  
0156 562  
0156 563  
0156 564  
0156 565  
0156 566  
0134 C5 94 0156 567  
0156 568  
0156 569  
0156 570  
0156 571  
0156 572  
0156 573

```

0134 5E A5 14 90 0202 573 ;
0134 C5 02 8A 0202 574 ; MOVB #20,UCBSB_DIPL(R5)
0206 575 ; BICB #UCBSM_DHO,UCBSB_DHUFLG(R5); Actually its a DHV
0208 576
0208 577 12$:
0208 578
0208 579 ; Find out what kind of machine the device is connected to.
0208 580 ; This tells us what kind of mapping registers we have
0208 581
0208 582 CPUDISP <-
0208 583 YF_INITMAP,- ; 11/780
0208 584 YF_INITMAP,- ; 11/750
0208 585 YF_INITMAP,- ; 11/730
0208 586 YF_INITMAP,- ; 11/790
0208 587 YF_INITNULL,- ; unknown
0208 588 YF_INITNULL,- ; unknown
0208 589 YF_NOMAP,- ; Seahorse
0208 590 YF_INITMAP- ; Mayflower
0208 591 >
0227 592 ; Unknown processor type
0227 593 YF_INITNULL:
0227 594
0227 595 ; prevent DMA being used, because we do not understand how the adapter
0227 596 ; works.
0227 597
0122 04 AA 0227 598 BICW #TTYSM_PC_DMAVL,-; SHOW DMA FEATURE NOT AVAILABLE FOR USE
0122 C5 0229 599 UCBSW_TT_PRTCTL(R5) ; IN PORT LEVEL
022C 600
022C 601 BRB INIT_CONTINUE
022E 602 ; These processors have map registers for DMA operation
022E 603 YF_INITMAP:
022E 604
0134 C5 01 88 022E 605 BISB #UCBSM_MAP,UCBSB_DHUFLG(R5)
0233 606 BRB INIT_CONTINUE
0233 607
0235 608 ; These processors do not have map registers
0235 609
0235 610 YF_NOMAP:
0235 611 ; No bits set
0235 612
0235 613 INIT_CONTINUE:
0235 614
0235 615 ;SET MODE CODE NEEDS TO TOGGLE THESE BITS
0235 616
000009EB'EF 16 0235 617 JSB YF$SET_LINE ; INIT SPEED/PARITY
023B 618
023B 619
023B 620 ; ENABLE LINE RECEIVER , TRANSMITTER AND MODEM INTERRUPTS
023B 621
023B 622
023B 623
23 64 A5 04 E1 023B 623 BBC #UCBSV_ONLINE,UCBSW_STS(R5),20$ ; TEST ONLINE
0240 624 SETIND R4
0247 625 CLRB DHUTBF2+1(R4) ; assume transmitter should
024A 626 ; be disabled
024A 627 BISW #DHULCTSM_ABORT,DHULCT(R4) ; assume abort to be set
024E 628
0F 012A C5 07 E0 024E 629 BBS #UCBSV_TT_DSBL,UCBSB_TT_MAINT(R5),20$ ; Test if disabled
```



```
08 A4 0104 8F A8 0254 630
08 A4 01 AA 0254 631 BISW #DHULCTSM_RCV!DHULCTSM MODEM,DHULCT(R4) ; enable receiver and modem
0D A4 80 8F 90 025A 632 BICW #DHULCTSM_ABORT,DHULCT(R4) ; clear abort bit
025E 633 MOVW #^X80,DHUTBF2+1(R4) ; enable transmitter
0263 634 20$:
0263 635
0263 636 : INIT RECEIVER MODEM STATUS FOR DHU
0263 637
0263 638
0263 639 MOVW DHUSTT(R4),R0
0267 640
0267 641 : Unfortunately the DHU/DHV dont put the modem bits where we want them
0267 642 : To get the correct bits we have to move RI,DCD,CTS up one place, while not
0267 643 : changing DSR. spare bits have to be ignored.
0267 644 ADDL R0,R0 ; (This shifts DSR out of bottom byte)
026A 645 BICB #^C<TTSM_DS_RING!TTSM_DS_CTS!TTSM_DS_CARRIER>,R0
026E 646 MOVW R0,UCBSB-TT-DS_RCV(R5) ; UPDATE CURRENT INPUT MODEM SIGNALS
0273 647 BBC #DHUSTT$V_DSR+T,R0,25$
0277 648 BBSS #TT$V_DS_DSR,UCBSB-TT-DS_RCV(R5),25$
027D 649 25$:
027D 650 MOVZBL #MODEMSC_INIT,R1 ; ASSUME INIT MODEM PROTOCOL
0280 651 MOVL UCBSL TT-CLASS(R5),R0 ; ADDRESS CLASS VECTOR TABLE
0285 652 JSB @CLASS_DS_TRAN(R0) ; INVOKE TO INIT MODEM PROTOCOL
0288 653 30$:
0288 654 BBC #UCBS$V_POWER,UCBSW_STS(R5),40$; DID WE DETECT A POWER FAIL
028D 655 MOVL UCBSL TT-CLASS(R5),R0 ; GET THE CLASS VECTOR TABLE ADDRESS
0292 656 JMP @CLASS_POWERFAIL(R0) ; AND GOTO THE POWERFAIL CODE
0295 657
0295 658 40$: RSB
0296 659
0296 660 : ERROR DETECTED DURING INITIALIZATION
0296 661
0296 662
0296 663 YF$UNIT_ERROR:
0296 664 BICW #UCBSM_ONLINE,UCBSW_STS(R5) ; UNIT NOT ON LINE
029A 665 RSB
029B 666
```

```
0298 668 .SBTTL MAINTENANCE ROUTINES
0298 669
0298 670 ++ YFSMAINT - MAINTENANCE FUNCTIONS
0298 671
0298 672 FUNCTIONAL DESCRIPTION:
0298 673 THIS ROUTINE PERFORMS MAINTENANCE FUNCTIONS FOR THE DHU
0298 674 (LOOPBACK IS ONLY ALLOWED ON LINES 0 AND 1)
0298 675
0298 676 INPUTS:
0298 677
0298 678 R5 = UCB ADDRESS
0298 679 UCB$B_TT_MAINT = FUNCTION TO BE PERFORMED
0298 680
0298 681 OUTPUTS:
0298 682 R0-R4 SCRATCH
0298 683
0298 684
0298 685 YFSMAINT:
012A 01 93 0298 686 BITB #IOSM_LOOP@-7,- ; LOOPBACK FUNCTION
0298 687 UCB$B_TT_MAINT(R5)
0298 688 BEQL 5$ ; NO
52 02 3C 02A0 688 BEQL 5$ ; SPECIFY LOOPBACK CODE
0298 689 MOVZWL #^X02,R2
0298 690 BRB 10$
0298 691 5$:
0298 692 BITB #IOSM_UNLOOP@-7,- ; RESET LOOPBACK FUNCTION
0298 693 UCB$B_TT_MAINT(R5)
0298 694 BEQL 15$ ; NO
52 00 3C 02A9 694 BEQL 15$ ; SPECIFY UNLOOP CODE
0298 695 MOVZWL #^X00,R2
0298 696 10$:
0298 697 SETIND
0298 698 MOVW DHULCT(R0),R1
51 02 51 08 A0 B0 02C0 698 INSV R2,DHULCT$V_MAINT,#2,R1 ; SET MAINT FIELD
0298 699 MOVW R1,DHULCT(R0) ; Update
0298 700 MOVZBL #1,R0 ; INDICATE SUCCESS
0298 701 RSB
0298 702 50$:
0298 703 CLRL R0
0298 704 RSB
0298 705
0298 706 15$:
0298 707 BITB #IOSM_AUTOXOF_ENA@-7,- ; AUTOXON ENABLED
0298 708 UCB$B_TT_MAINT(R5) ; NO THEN MAYBE DISABLE
0298 709 BEQL 17$
0298 710 BISW #TTY$M_PC_XOFAVL,- ; SET THE BIT AVAILABLE
0298 711 UCB$W_TT_PRTCTL(R5)
0298 712
0298 713 17$:
0298 714 BITB #IOSM_AUTOXOF_DIS@-7,- ; AUTOXON disabled
0298 715 UCB$B_TT_MAINT(R5) ; no then don't disable it
0298 716 BEQL 19$
0298 717 BICW #TTY$M_PC_XOFAVL,-
0298 718 UCB$W_TT_PRTCTL(R5)
0298 719
0298 720 19$:
0298 721 BITB #IOSM_LINE_OFF@-7,- ; LINE OFF
0298 722 UCB$B_TT_MAINT(R5) ; NO
0298 723 BEQL 30$
0298 724 SETIND
```

```
08 A0 0104 8F AA 0304 725 BICW #DHULCT$M_RCV!DHULCT$M_MODEM,DHULCT(R0) ; Disable Receive and modem
      08 A0 01 AB 030A 726 BISW #DHULCT$M_ABORT,DHULCT(R0) ; Abort any current activity
      OD A0 94 030E 727 CLRB DHUTBF2+1(R0) ; Disable Transmit
      25 11 0311 728 BRB 40$
      10 93 0313 729 30$:
      012A C5 0313 730 BITB #IOSM_LINE_ON@-7- ; LINE ON
      B7 13 0315 731 UCB$B_TT_MAINT(R5)
      08 A0 0104 8F AB 0329 732 BEQL 50$ ; NO
      08 A0 01 AA 032F 733 SETIND
      OD A0 80 8F 90 0333 734 BISW #DHULCT$M_RCV!DHULCT$M_MODEM,DHULCT(R0) ; Enable Receive and modem
      50 01 9A 0338 735 BICW #DHULCT$M_ABORT,DHULCT(R0)
      05 033B 736 MOVB #^X80,DHUTBF2+1(R0) ; Enable Transmit
      033C 737 40$:
      033C 738 MOVZBL #1,R0
      739 RSB
      740
```



```
033C 742 .SBTTL OUTPUT MODEM CONTROL
033C 743 :++
033C 744 YF$DS_SET - SET OUTPUT MODEM SIGNALS
033C 745 :
033C 746 FUNCTIONAL DESCRIPTION:
033C 747 :
033C 748 THIS ROUTINE OUTPUTS THE OUTPUT MODEM SIGNALS FOR THE SPECIFIED UNIT
033C 749 :
033C 750 INPUTS:
033C 751 :
033C 752 R2 = LOW BYTE - SIGNALS TO ACTIVATE
033C 753 HIGH BYTE - SIGNALS TO DEACTIVATE
033C 754 :
033C 755 R5 = UCB ADDRESS
033C 756 :
033C 757 OUTPUTS:
033C 758 :
033C 759 R0-R3 ARE USED.
033C 760 :--
033C 761 YF$DS_SET:
033C 762 :
033C 763 Check that the DHU/DHV modem control signals have the standard values
033C 764 :
033C 765 BISB R2,UCB$B_TT_DS_TX(R5) ; SET NEW OUTPUT SIGNALS
52 0125 C5 52 88 0341 766 ASHL #-8,R2,R2 ; ACCESS SIGNALS TO RESET
0341 767 BICB R2,UCB$B_TT_DS_TX(R5) ; RESET THEM
0346 768 SETIND
7E 0125 C5 ED 8F 88 035A 769 BICB3 #^C<<DHULCT$M_DTR!DHULCT$M_RTS>/256>,UCB$B_TT_DS_TX(R5),-(SP);
0361 770 :
0361 771 The DHU/DHV is set to report modem change events in the receive fifo
0361 772 (Unless the line is disabled)
0361 773 :
03 012A C5 07 E0 0361 774 BBS #UCB$V_TT_DSBL,UCB$B_TT_MAINT(R5),10$ ; Test if disabled
0367 775 BISB #<DHULCT$M_MODEM/256>,(SP)
036A 776 10$:
09 A0 8E 90 036A 777 MOVB (SP)+,DHULCT+1(R0) ; OUTPUT NEW VALUE
036E 778 :
05 036E 779 RSB
036F 780 :
036F 781 :
```

```
036F 783 .SBTTL RECEIVER INTERRUPT SERVICE
036F 784 :++
036F 785 :YF$INTINP - DHU RECEIVER READY INTERRUPTS
036F 786 :
036F 787 :FUNCTIONAL DESCRIPTION:
036F 788 :
036F 789 :THIS ROUTINE IS ENTERED WHEN A CHARACTER IS AVAILABLE IN THE UNIT'S
036F 790 :SILO. THE CHARACTER IS EXTRACTED AND IS PASSED TO THE ASSOCIATED
036F 791 :CLASS DRIVER. IF THE CLASS DRIVER RETURNS CHARACTER(S) THEN NEW
036F 792 :OUTPUT IT INITIATED (NORMALLY ECHO).
036F 793 :
036F 794 :INPUTS:
036F 795 :
036F 796 :    00(SP) = ADDRESS OF IDB
036F 797 :
036F 798 :IMPLICIT INPUTS:
036F 799 :
036F 800 :    R0,R1,R2,R3,R4,R5 ARE SAVED ON STACK.
036F 801 :
036F 802 :OUTPUTS:
036F 803 :
036F 804 :    THE INTERRUPT IS DISMISSED WHEN THE SILO IS EMPTY.
036F 805 :
036F 806 :--
036F 807 YF$INTINP:: : DHU/DHV INPUT INTERRUPTS
036F 808 :
036F 809 :GET THE CSR ADDRESS
036F 810 :
036F 811 :    MOVL    @ (SP)+,R4 : GET THE IDB ADDRESS
036F 812 :    PUSHL   R4         : SAVE IDB ADDRESS
036F 813 :    MOVL    (R4),R0    : GET THE CSR ADDRESS
036F 814 :
036F 815 :GET THE CHARACTER FROM THE INTERFACE
036F 816 :
036F 817 25$: MOVW    DHURBF(R0),R3 : Get the silo entry
036F 818 :    BGEQ    45$         : Silo empty (== BRW 100$)
036F 819 :    ASHL    #-8, R3, R2 : shift the line number
036F 820 :    BICL    #^C<15>, R2 : use mask to obtain line number
036F 821 :    MOVL    IDB$L_UCBLST(R4)[R2],R5 : GET THE UCB FOR THAT LINE
036F 822 :    BEQL    25$         : IF EQL THEN NOT THERE
036F 823 :    BITW    #<DHURCVSM_PARERR>!--
036F 824 :    <DHURCVSM_OVERRUN>!--
036F 825 :    <DHURCVSM_FRAMER>,R3 : ERRORS OR MODEM TRANSITION ?
036F 826 :
036F 827 :    BNEQ    50$         : YES, PROCESS THEM
036F 828 27$:
036F 829 :    MOVZBL  R3,R3       : CLEAR THE HIGH BYTES OF CHARACTER
036F 830 :    JSB     @UCB$L_TT_PUTNXT(R5) : BUFFER THE CHARACTER
036F 831 :    BLEQ    40$         : NONE OR STRING OUTPUT
036F 832 :    TIMSET  #1,R1,LOCKOUTPUT : SET TIMEOUT AND INTERRUPT BIT
036F 833 :    SETIND  R0
036F 834 :    BBS     #UCB$V_DHU,UCB$B_DHUFLG(R5),28$
036F 835 :    BISW3   #^X8000,R3,DHUTXF(R0) : DHV single char output
036F 836 :    BRB     30$
036F 837 28$:
036F 838 :    MOVB    R3,DHUTXF(R0) : DHU tifo output
036F 839 30$: MOVL    (SP),R4 : GET IDB ADDRESS
```

```

      97 11 03DE 840      BRB 25$      : CONTINUE
      03E0 841 40$:
00000443 F9 13 03E0 842      BEQL 30$      : NO CHARACTER
      EF 16 03E2 843      JSB BURST_OUTPUT : START BURST
      F1 11 03E8 844      BRB 30$
      03EA 845
      03EA 846 45$:
      18 11 03EA 847      BRB 100$
      03EC 848
      03EC 849 50$:
      03EC 850
      03EC 851 : PROCESS PARITY, FRAME OVERRUN ERROR OR MODEM TRANSITION
      03EC 852
      03EC 853
      03EC 854 : The DHU indicates modem transition by setting all the
      03EC 855 : error bits
      03EC 856      BBC #DHURCVSV_PARERR,R3,60$
      04 53 0C E1 03F0 857      BBC #DHURCVSV_OVERRUN,R3,60$
      19 53 0D E0 03F4 858      BBS #DHURCVSV_FRAMER,R3,200$; Modem transition if all set
      03F8 859 60$:
52 0114 C5 D0 03F8 860      MOVL UCB$L TT_CLASS(R5),R2 : GET CLASS DISPATCH
      14 B2 16 03FD 861      JSB @CLASS_READERROR(R2) : SIGNAL ERROR
      95 12 0400 862      BNEQ 27$ : CHRRACTER TO ECHO
      0402 863 70$:
      D7 11 0402 864      BRB 30$
      0404 865
      5E 04 C0 0404 866 100$: ADDL #4,SP : REMOVE IDB ADDRESS
      50 8E 7D 0407 867      MOVQ (SP)+,R0 : RESTORE REGISTERS
      52 8E 7D 040A 868      MOVQ (SP)+,R2
      54 8E 7D 040D 869      MOVQ (SP)+,R4
      02 0410 870      REI
      0411 871
      0411 872 : Modem transition routine
      0411 873
      0411 874 200$:
      0411 875 : If lsb set then it is a self test code
      0411 876 : We currently ignore self test codes, although these could be used
      0411 877 : for error logging purposes
      0411 878
      C7 53 E8 0411 879      BLBS R3,30$
      0414 880
      0414 881 : Unfortunately the DHU and DHV dont put the modem bits where we want them
      0414 882 : To get the correct bits we have to move R1,DCD,CTS up one place, while not
      0414 883 : changing DSR. spare bits have to be ignored.
      53 53 53 C0 0414 884      ADDL R3,R3 : (This shifts DSR out of bottom byte)
      53 8F 8F 8A 0417 885      BICB #^C<TTSM_DS_RING!TTSM_DS_CTS!TTSM_DS_CARRIER>,R3
      04 53 08 E1 041B 886      BBC #DHUSTT$V_DSR+1,R3,210$
      00 53 07 E2 041F 887      BBSS #TT$V_DS_DSR,R3,210$
      0423 888 210$:
0124 C5 53 90 0423 889      MOVB R3,UCB$B_TT_DS_RCV(R5) : UPDATE CURRENT INPUT MODEM SIGNALS
      52 53 90 0428 890      MOVB R3,R2 : PASS CURRENT INPUT MODEM SIGNALS IN R2
      51 03 9A 042B 891      MOVZBL #MODEMSC_DATASET,R1 : TRANSITION TYPE IS DATASET
      50 DD 042E 892      PUSHL R0 : SAVE CSR ADDRESS
      54 0114 C5 D0 0430 893      MOVL UCB$L TT_CLASS(R5),R4 : GET CLASS DISPATCH
      0C B4 16 0435 894      JSB @CLASS_DS_TRAN(R4) : INVOKE TRANSITION ROUTINE
      50 8ED0 0438 895      POPL R0 : RESTORE CSR ADDRESS
      FF9D 31 043B 896      BRW 30$
```

YFDRIIVER  
V04-000

- Port Driver for DHU/DHV  
RECEIVER INTERRUPT SERVICE

F 7

16-SEP-1984 02:26:48 VAX/VMS Macro V04-00  
5-SEP-1984 04:17:43 [TTDRVR.SRC]YFDRIIVER.MAR;1

Page 21  
(1)

043E 897  
043E 898

YFDI  
V04-



```
043E 900 .SBTTL START I/O ROUTINE
043E 901 :++
043E 902 YF$STARTIO - START I/O OPERATION ON DHU
043E 903
043E 904 FUNCTIONAL DESCRIPTION:
043E 905
043E 906 THIS ROUTINE IS ENTERED FROM THE DEVICE INDEPENDENT TERMINAL STARTIO
043E 907 ROUTINE TO ENABLE OUTPUT INTERRUPTS ON AN IDLE DHU UNIT.
043E 908
043E 909 INPUTS:
043E 910
043E 911 R3 = CHARACTER AND CC = PLUS
043E 912 ADDRESS AND CC = NEGATIVE
043E 913
043E 914 R5 = UCB ADDRESS
043E 915
043E 916 OUTPUTS:
043E 917
043E 918 R5 = UCB ADDRESS
043E 919 :--
043E 920 .ENABLE LSB
043E 921 YF$STARTIO:: ; START I/O ON UNIT
043E 922 BLSS BURST_OUTPUT
0440 923 BRW 90$
0443 924
0443 925 BURST_OUTPUT:
0443 926 SETIND
0452 927 MOVZWL UCBSW TT_OUTLEN(R5),R2 ; GET LENGTH
0457 928 BBC #TTY$V PC_DMAENA,- ; USE SILO IF DMA NOT ENABLED ON THIS LINE
0459 929 UCBSW TT_PRTCTL(R5),SILO_OUTPUT
045D 930 CMPW R2,G-TTY$GW_DMA_SIZE ; LARGE ENOUGH FOR DMA
0464 931 BLSS SILO_OUTPUT
0466 932 10$: BRW DMA_START ; YES SO DO DMA
0469 933
0469 934 SILO_OUTPUT:
0469 935 BBC #UCBSV DHU,UCBSB_DHUFLG(R5),200$ ; DHV has single char output
046F 936 MOVZBL DHUTXF(R0),R1 ; get number of slots
0473 937 CMPW R2,R1 ; BURST LARGER THAN SILO?
0476 938 BLEQU 50$ ; NO
0478 939 MOVZBL R1,R2 ; SLOTS AVAILABLE IS MAXIMUM
047B 940 50$:
047B 941 MOVL UCBSL TT_OUTADR(R5),R3 ; GET ADDRESS
0480 942 ADDL R2,UCBSL TT_OUTADR(R5) ; UPDATE POINTER
0485 943 SUBW R2,UCBSW TT_OUTLEN(R5) ; AND COUNT
048A 944 BEQL 60$ ; ALL DONE, NO NEED FOR BURST
048C 945 BLSW #TTY$M TANK_BURST,- ; SIGNAL BURST ACTIVE
0490 946 UCBSW TT_HOED(R5)
0493 947 60$:
0493 948 BLBC R2,70$ ; EVEN TRANSFER
0495 949 MOVB (R3)+,DHUTXF(R0) ; OUTPUT ODD BYTE
049A 950 DECL R2 ; UPDATE COUNT
049C 951 BEQL 80$ ; DONE
049E 952 70$:
049E 953 ASHL #-1,R2,R2 ; CONVERT TO WORD COUNT
04A3 954 75$:
04A3 955 MOVW (R3)+,DHUTXF(R0)
04A7 956 DELAY ; TO RELEASE THE UNIBUS
```

```
F6 52  F5 04AA 957      SOBGTR R2,75$      ; LOOP TILL DONE
          04AD 958
          05 04AD 959 80$:  RSB              ; RETURN TO CALLER
          04AE 960
          04AE 961 90$:
          22 13 04AE 962      BEQL      100$      ; SKIP IF NONE
          04B0 963      SETIND
09 0134 C5 01 E0 04BF 964      BBS      #UCB$V_DHU,UCB$B_DHUFLG(R5),95$
          04C5 965      ;
          04C5 966      ; DHV single character output
          04C5 967      ;
02 A0  53  8000 8F A9 04C5 968      BISW3  #^X8000,R3,DHUTXC(R0)
          04 11 04CC 969      BRB      100$
          04CE 970      ;
          04CE 971      ; DHU fifo output
          04CE 972      ;
          04CE 973 95$:
          06 A0  53  90 04CE 974      MOVB      R3,DHUTXF(R0)
          04D2 975 100$:
          05 04D2 976      RSB
          04D3 977      ;
          04D3 978      ; DHV 'silo' output, uses single character mode
          04D3 979      ;
          04D3 980 200$:
          53  011C D5 9A 04D3 981      MOVZBL  @UCB$L_TT_OUTADR(R5),R3 ; GET character
          011C C5 D6 04D8 982      INCL      UCB$L_TT_OUTADR(R5) ; UPDATE POINTER
          0120 C5 B7 04DC 983      DECW      UCB$W_TT_OUTLEN(R5) ; AND COUNT
          07 13 04E0 984      BEQL      260$ ; ALL DONE, NO NEED FOR BURST
          0800 8F AB 04E2 985      BISW      #TTY$M_TANK_BURST,- ; SIGNAL BURST ACTIVE
          0108 C5 04E6 986      UCB$W_TT_HOLD(R5)
          04E9 987 260$:
02 A0  53  8000 8F A9 04E9 988      BISW3  #^X8000,R3,DHUTXC(R0) ; output the character
          05 04F0 989      RSB
          04F1 990
          04F1 991      .DISABLE      LSB
          04F1 992
```

```
04F1 994 .SBTTL PORT DMA ROUTINES
04F1 995
04F1 996 ++ DMA_START - INITIATE DMA OUTPUT
04F1 997
04F1 998 FUNCTIONAL DESCRIPTION:
04F1 999
04F1 1000 THESE ROUTINES ARE CALLED BY THE PORT INPUT INTERRUPT, OUTPUT
04F1 1001 INTERRUPT, AND STARTIO TO INITIATE NEW DMA OUTPUT.
04F1 1002 THEY HANDLE ALLOCATION AND LOADING OF MAP REGISTERS
04F1 1003 TO HANDLE DMA OUTPUT. MAP REGISTERS ARE ALLOCATED IN PAIRS
04F1 1004 TO ALLOW OUTPUT BURSTS UP TO 512 BYTES. TRANSFERS LARGER THAN
04F1 1005 THAT ARE DONE IN SEGMENTS. IF INSUFFICIENT MAPS ARE AVAILABLE,
04F1 1006 THE TRANSFER IS DONE SILO MODE.
04F1 1007
04F1 1008
04F1 1009 INPUTS:
04F1 1010
04F1 1011 R5 = UCB ADDRESS
04F1 1012
04F1 1013 OUTPUTS:
04F1 1014
04F1 1015 R5 = UCB ADDRESS
04F1 1016
04F1 1017 R0 PRESERVED
04F1 1018 R1,R2,R3,R4 DESTROYED
04F1 1019 --
04F1 1020 DMA_START:
04F1 1021 BISW #TTYSM_TANK_DMA, - : SHOW DMA MODE ACTIVE
04F5 1022 UCBSW_TT_HOLD(R5)
04F8 1023 BBCC #TTY$V_TP_ABORT, - : RESET ANY OLD ABORT REQUESTS
04FA 1024 UCBSB_TP_STAT(R5),3$
04FE 1025 BICW #DHULCTSM_ABORT, DHULCT(R0)
0502 1026
0502 1027 : If there are no mapping registers for the device then don't allocate them
0502 1028
0502 1029 5$: BBC #UCBSV_MAP, UCBSB_DHUFLG(R5),DMA_CONTINUE
0508 1030 : CHECK IF UNIT HAS PERMANENT MAP REGISTERS
0508 1031
0508 1032 BBC #TTY$V_PC_PRRMAP, - : SKIP IF NOT AUTHORIZED FOR PERM MAPS
050A 1033 UCBSW_TT_PRTCTL(R5),5$
050E 1034 BBS #TTY$V_PC_MAPAVL, - : SKIP FORK IF MAPS ALLOCATED ALREADY
0510 1035 UCBSW_TT_PRTCTL(R5),DMA_CONTINUE
0514 1036 5$:
0514 1037 BISB #TTYSM_TP_ALLOC, - : SHOW ALLOC FORK ACTIVE
0516 1038 UCBSB_TP_STAT(R5)
0519 1039 MOVL UCBSL_TT_CLASS(R5),R1 : GET CLASS VECTOR ADDRESS
051E 1040 JSB @CLASS_FORK(R1) : FORK TO FIPL FOR MAP
0521 1041 : REGISTER ALLOCATION
0521 1042 RSB : RETURN TO CALLER WITH
0522 1043 : "INT" LEFT ON TO INTERLOCK
0522 1044 : OUTPUT. FORK ROUTINE WILL
0522 1045 : RESUME AT DMA_ALLOC.
0522 1046 DMA_ALLOC:
0522 1047
0522 1048
0522 1049 5$:
0522 1050 MOVZBL #2,R3 : REQUEST 2 MAP REGISTERS
```

1000 8F AB 04F1 1021  
0108 C5 E5 04F5 1022  
04 0130 C5 00 04F8 1023  
08 A0 01 AA 04FA 1024  
0502 1025  
0502 1026  
0502 1027  
55 0134 C5 00 E1 0502 1029  
0508 1030  
0508 1031  
06 0122 C5 03 E1 0508 1032  
04 0122 C5 E0 050A 1033  
0510 1034  
0514 1035  
0514 1036  
0130 C5 02 88 0514 1037  
0114 C5 D0 0516 1038  
1C B1 16 0519 1039  
051E 1040  
0521 1041  
0521 1042  
0522 1043  
0522 1044  
0522 1045  
0522 1046  
0522 1047  
0522 1048  
53 02 9A 0522 1049  
0522 1050

```
00000000'GF 16 0525 1051 JSB G*IOCSALOUBAMAPN ;
0528 1052
052B 1053
0122 10 AB 052F 1054 SETIPL UCBSB_DIPL(R5) ; INTERLOCK TO DEVICE IPL
0531 1055 BISM #TTY$M_PC_MAPAVL - ; SHOW MAP ALLOCATED
0130 02 8A 0534 1056 UCBSW_TP_PRTCTL(R5)
0536 1057 BICB #TTY$M_TP_ALLOC - ; SHOW ALLOC FORK DONE
17 50 E8 0539 1058 UCBSB_TP_STAT(R5)
053C 1059 BLBS R0,20$ ; SUCCESS
50 24 A5 D0 053C 1060 MOVL UCBSL_CRB(R5),R0 ; GET CRB OF UNIT
50 2C B0 D0 0540 1061 MOVL @CRB$C_INTD+VEC$SL_IDB(R0),R0 ; GET CSR
100C 8F AA 0544 1062 BICW #TTY$M_TANK_DMA - ; RESET DMA MODE
0108 C5 0548 1063 UCBSW_TP_HOLD(R5)
52 0120 C5 3C 054B 1064 MOVZWL UCBSW_TP_OUTLEN(R5),R2 ; RESTORE OUTPUT LENGTH
FF16 31 0550 1065 BRW SILO_OUTPUT ; USE SILO FOR OUTPUT
0553 1066
0553 1067 20$:
50 24 A5 D0 0553 1068 MOVL UCBSL_CRB(R5),R0 ; GET CRB ADDRESS
34 A0 D0 0557 1069 MOVL CRB$C_INTD+VEC$M_MAPREG(R0),-
012C C5 055A 1070 UCBSL_TP_MAP(R5) ; SAVE MAP FIELD IN UCB
055D 1071
055D 1072
055D 1073 DMA_CONTINUE:
0C 0130 00 E0 055D 1074 BBS #TTY$V_TP_ABORT - ; BRANCH IF DMA TO BE ABORTED
055F 1075 UCBSB_TP_STAT(R5),2$
0563 1076
53 011C C5 D0 0563 1077 MOVL UCBSL_TP_OUTADR(R5),R3 ; GET ADDRESS OF NEXT STRING
52 0120 C5 3C 0568 1078 MOVZWL UCBSW_TP_OUTLEN(R5),R2 ; LENGTH OF OUTPUT
03 12 056D 1079 BNEQ 4$ ; SKIP IF MORE TO DO
0162 31 056F 1080 2$: BRW DMA_DONE ; BRANCH IF TRANSFER IS DONE
50 DD 0572 1081 4$:
0572 1082 PUSHL R0 ; SAVE INPUT VOLITAL REGISTER "CSR"
0574 1083
0574 1084
0574 1085 ; If there are no mapping registers for the device then
0574 1086 ; start dma directly
0574 1087
03 0134 C5 00 E1 0574 1088 BBC #UCBS$V_MAP, UCBSB_DHUFLG(R5),DMA_NOMAP
00A0 31 057A 1089 BRW DMA_MAP
```



```
057D 1091 DMA_NOMAP:
057D 1092
057D 1093 Special code to work with an unmapped DHU/DHV
057D 1094 (I.e. Seahorse configuration)
057D 1095
057D 1096 this code examines the DMA buffer to find the maximum physically
057D 1097 contiguous area, and starts a DMA on that part.
057D 1098
057D 1099 It assumes that the buffer is in non-paged pool
057D 1100 (I.e. that it is in system address space and that the PTE
057D 1101 will always contain the PFN for the page)
057D 1102
057D 1103 Find physical address of first page
057D 1104
057D 1105 MOVL UCBSL TT_OUTADR(R5),R3
54 53 53 011C C5 D0 0582 1106 BICL3 #^X80000000,R3,R4 ; CALC SVAPTE OF BUFFER
54 54 54 F7 8F 78 058A 1107 ASHL #9,R4,R4 ; ISOLATE PAGE
50 00000000 GF D0 058F 1108 MOVL G^MMG$GL_SPTBASE,R0 ; GETS SVAPTE OF BUFFER
54 54 6044 DE 0596 1109 MOVAL (R0)[R4],R4 ; INTO R4
53 FFFFE00 8F CA 059A 1110 BICL #^C^X1FF,R3 ; COMPUTE BYTE OFFSET IN PAGE
05A1 1111
05A1 1112 calculate length of DMA in this page
05A1 1113
05A1 1114 SUBL3 R3,#512,R1
51 00000200 8F 53 C3 05A9 1115
05A9 1116 See if this is longer than buffer
05A9 1117
05A9 1118 CMPW R1,UCBSW_TT_OUTLEN(R5)
05AE 1119 BLEQ 10$
05B0 1120 MOVW UCBSW_TT_OUTLEN(R5),R1 ; use actual buffer length
05B5 1121 10$:
05B5 1122 SU3W R1,UCBSW_TT_OUTLEN(R5)
05BA 1123
05BA 1124 Get the PFN for the first page
05BA 1125
05BA 1126 MOVL (R4)+,R2
05BD 1127
05BD 1128 calculate physical address from PTE
05BD 1129 (assuming that it fits into a 22-bit address)
05BD 1130
05BD 1131 EXTZV #0,#21,R2,R2 ; get PFN only
52 52 15 00 EF 05C2 1132 INSV R2,#9,#13,R3
53 00 09 52 F0 05C7 1133
05C7 1134 Loop through remaining pages to see if they are contiguous with this one
05C7 1135
05C7 1136 20$:
05C7 1137 TSTW UCBSW_TT_OUTLEN(R5)
05CB 1138 BEQL 50$ ; No more DMA
05CD 1139 INCL R2 ; get expected PTE
52 64 15 00 ED 05CF 1140 CMPZV #0,#21,(R4),R2 ; test next PTE
05D4 1141 BNEQ 50$ ; not contiguous
05D6 1142 TSTL (R4)+ ; step to next PTE
05D8 1143
05D8 1144 concatenate this page to previous DMA
05D8 1145
0200 8F 0120 C5 B1 05D8 1146 CMPW UCBSW_TT_OUTLEN(R5),#512
05DF 1147 BLEQ 40$ ; partial page
```

```

51 00000200 8F C0 05E1 1148
0120 C5 0200 8F A2 05E1 1149      ADDL #512,R1      ; whole page gets added
                                SUBW #512,UCB$W_TT_OUTLEN(R5)
                                BRB 20$
                                05EF 1151
                                05F1 1152
                                05F1 1153 ; partial page gets added, to complete the DMA
                                05F1 1154 40$:
51 0120 C5 A0 05F1 1155      ADDW UCB$W_TT_OUTLEN(R5),R1
0120 C5 B4 05F6 1156      CLRW UCB$W_TT_OUTLEN(R5)
                                05FA 1157 50$:
                                05FA 1158
                                05FA 1159 : Start up the DMA
                                05FA 1160
011C C5 51 C0 05FA 1161      ADDL R1,UCB$L_TT_OUTADR(R5) ; step to next DMA address
                                50 BED0 05FF 1162      POPL R0      ; RESTORE CSR ADDRESS
                                0602 1163      SETIND R0
                                OE A0 51 B0 0609 1164      MOVW R1,DHUTCT(R0) ; load the count
                                OA A0 53 B0 060D 1165      MOVW R3,DHUTBF1(R0) ; load low address
53 53 06 10 EF 0611 1166      EXTZV #16,#6,R3,R3 ; get high address
OC A0 53 80 8F 89 0616 1167      BISB3 #^X80,R3,DHUTBF2(R0) ; load high address and start
                                05 061C 1168      RSB
```

```
00000200 8F 52 D1 061D 1170 : Code to do mapped DMA transfers
      52 0200 8F 3C 061D 1171 : DMA_MAP:
      011C C5 52 C0 061D 1172 : CMPL R2,#512 : NEXT BURST TOO LONG FOR MAPS?
      0120 C5 52 A2 061D 1173 : BLEQ 5$ : NO
      21 0134 C5 02 E0 0624 1174 : MOVZWL #512,R2
      062B 1177 :
      062B 1178 :
      062B 1179 5$: ADDL R2,UCBSL_TT_OUTADR(R5) : UPDATE CHARACTER POINTER FOR NEXT TIME
      0630 1180 : SUBW R2,UCBSW_TT_OUTLEN(R5) : UPDATE COUNT FOR NEXT TIME
      0635 1181 :
      0635 1182 : BBS #U(BSV_XOFF,UCBSB_DHUFLG(R5),6$ : IF XOFF, DON'T SET TIMER
      063B 1183 : TIMSET R2,R1,LOCKOUTPUT : RECOMPUTE TIMEOUT VALUE FOR THIS
      065C 1184 : : PORTION OF THE DMA BURST
      065C 1185 :
      065C 1186 :
      065C 1187 : R3 - STRING ADDRESS
      065C 1188 : R2 - LENGTH
      065C 1189 : R5 - UCB
      065C 1190 :
      50 24 BB 065C 1191 6$: PUSH R2,R5>
      51 24 A5 DO 065E 1192 : MOVL UCB$C_CRB(R5),R0 : GET CRB ADDRESS
      51 38 B0 DO 0662 1193 : MOVL @CRB$C_INTD+VEC$C_ADP(R0),R1 : CONFIG REGISTER
      50 OF 00 EF 0666 1194 : EXTZV #VEC$V_MAPREG,#VEC$S_MAPREG,-
      51 012C C5 0669 1195 : MOVL UCB$C_TP_MAP(R5),R0 : GET STARTING MAP REGISTER
      51 0800 C140 DE 066D 1196 : MOVL UBASL_MAP(R1)[R0],R1 : GET 1ST MAP REGISTER ADDRESS
      54 53 80000000 8F CB 0673 1197 :
      54 54 F7 8F 78 0673 1198 : BICL3 #^X80000000,R3,R4 : CALC SVAPTE OF BUFFER
      55 00000000 GF DO 067B 1199 : ASHL #-9,R4,R4 : ISOLATE PAGE
      54 6544 DE 0680 1200 : MOVL G^MMG$GL_SPTBASE,R5 : GETS SVAPTE OF BUFFER
      53 FFFFFFFE00 8F CA 0687 1201 : MOVL (R5)[R4],R4 : INTO R4
      0688 1202 : BICL #^C^X1FF,R3 : COMPUTE BYTE OFFSET IN PAGE
      0692 1203 :
      0692 1204 : LOAD MAP REGISTERS
      0692 1205 : R0 - MAP REGISTER NUMBER
      0692 1206 : R1 - ADDRESS OF FIRST MAP REGISTER
      0692 1207 : R2 - BUFFER LENGTH
      0692 1208 : R3 - BYTE OFFSET IN PAGE
      0692 1209 : R4 - SVAPTE OF BUFFER
      52 02 9A 0692 1210 :
      55 84 DO 0692 1211 : MOVZBL #2,R2
      0695 1212 10$: MOVL (R4)+,R5 : GET CONTENTS OF NEXT PTE
      0698 1213 :
      0698 1214 : THIS CODE ASSUMES THAT DMA IS FROM NONPAGED POOL
      0698 1215 :
      55 0B 15 00000400 8F F0 0698 1216 : INSV #^X400,#21,#11,R5 : SET VALID BIT, DATA PATH 0
      81 55 DO 06A1 1217 : MOVL R5,(R1)+ : LOAD INTO MAP REGISTER
      EE 52 F5 06A4 1218 : SOBGTR R2,10$
      24 BA 06A7 1219 :
      06A7 1220 : POPR #^M<R2,R5> : RESTORE LENGTH,WRITE BUFFER, UCB
      06A9 1221 :
      06A9 1222 :
      06A9 1223 : Note that the following code works with 22 bit Qbus addresses
      06A9 1224 : As well as with 18 bit Unibus addresses
      53 0D 09 50 F0 06A9 1225 :
      06A9 1226 : INSV R0,#9,#13,R3 : COMPUTE UNIBUS ADDRESS
```

```

53 53 0C A0 53 06 80 8F 50 8E D0 05
OE A0 52 B0 06AE 1227 SETIND
OA A0 53 B0 06BD 1228 MOVW R2,DHUTCT(R0)
06 10 EF 06C1 1229 MOVW R3,DHUTBF1(R0)
53 53 06 10 EF 06C5 1230 EXTZV #16,#6,R3,R3
0C A0 53 80 8F 89 06CA 1231 BISB3 #^X80,R3,DHUTBF2(R0)
50 8E D0 05 06D0 1232 POPL R0
05 06D3 1233 RSB
06D4 1234
06D4 1235
06D4 1236 DMA_DONE:
06D4 1237 ; DMA COMPLETION
06D4 1238
06D4 1239 BBS #TTY$V_PC_PRMAP,- ; SKIP FORK IF MAPS PERMANENT
2E 0122 C5 E0 06D6 1240 UCBSW TT_PRTCTL(R5),DMA_POST
04 88 06DA 1241 BISB #TTY$M_TP_DLLOC,- ; SHOW DEALLOC FORK ACTIVE
0130 C5 06DC 1242 UCBSB_TP_STAT(R5)
51 0114 C5 D0 06DF 1243 MOVL UCBSL-TT-CLASS(R5),R1 ; GET CLASS VECTOR ADDRESS
1C B1 16 06E4 1244 JSB @CLASS_FORK(R1) ; SCHEDULE FORK TO FIPL FOR MAP
05 06E7 1245 RSB ; REGISTER DEALLOCATION
06E7 1246 ; RETURN TO CALLER, FORK WILL RESUME
06E8 1247 ; AT DMA_DEALLOC
06E8 1248
06E8 1249 DMA_DEALLOC:
50 24 A5 D0 06E8 1250 MOVL UCBSL-CRB(R5),R0 ; GET CRB ADDRESS
012C C5 D0 06EC 1251 MOVL UCBSL-TP_MAP(R5),-
34 A0 06F0 1252 CRBSL-INTD+VECSW_MAPREG(R0); RESTORE MAP FIELD IN CRB
06 13 06F2 1253 BEQL $$ ; SKIP IF NONE
00000000 GF 16 06F4 1254 JSB G^IOCSRELMAPREG ; RELEASE MAP REGISTERS
06FA 1255
06FA 1256 $$: SETIPL UCBSB DIPL(R5) ; INTERLOCK TO DEVICE IPL
06FE 1257 BICW #TTY$M_PC_MAPAVL,- ; SHOW MAP ALLOCATED
0122 C5 AA 0700 1258 UCBSW TT_PRTCTL(R5)
04 8A 0703 1259 BICB #TTY$M_TP_DLLOC,- ; SHOW DEALLOC FORK DONE
0130 C5 0705 1260 UCBSB_TP_STAT(R5)
0708 1261
0708 1262 DMA_POST:
0708 1263 BICB #TTY$M_TP_ABORT,- ; RESET ABORT REQUEST
0130 C5 070A 1264 UCBSB_TP_STAT(R5)
1000 8F AA 070D 1265 BICW #TTY$M_TANK_DMA,- ; RESET DMA MODE
0108 C5 0711 1266 UCBSW_TT_HOCD(R5)
0714 1267
0714 1268 : CALL GETNEXT TO CONTINUE PROCESSING
0714 1269 :
0714 1270 BICB #UCBSM_TIM!UCBSM_INT,- ; CLEAR TIMEOUT AND INT EXPECTED
64 A5 8A 0716 1271 UCBSW_STS(R5)
010C D5 16 0718 1272 JSB @UCBSL-TT_GETNXT(R5) ; GET NEXT BURST
FD1F 31 071C 1273 BRW YFS$STARTIO ; AND PROCEED
071F 1274 YFS$FORK:
071F 1275 SAVIPL ; SAVE CURRENT IPL ON THE STACK
0000073A EF DF 0722 1276 PUSHAL 20$ ; BUILD RETURN ADDRESS ON STACK
01 01 E1 0728 1277 BBC #TTY$V_TP_ALLOC,- ; SKIP IF NOT ALLOCATE FORK
03 0130 C5 072A 1278 UCBSB_TP_STAT(R5),10$
FDF1 31 072E 1279 BRW DMA_ACLOC ; RESUME AT ALLOCATE CODE THREAD
0731 1280 10$:
0731 1281 BBC #TTY$V_TP_DLLOC,- ; CHECK FOR DEALLOCATE
03 0130 C5 0733 1282 UCBSB_TP_STAT(R5),20$
FFAE 31 0737 1283 BRW DMA_DEALLOC
```



- Port Driver for DHU/DHV  
PORT DMA ROUTINES

16-SEP-1984 02:26:48 VAX/VMS Macro V04-00  
5-SEP-1984 04:17:43 [TTDRVR.SRC]YFDRIVER.MAR;1

Page 30  
(1)

	073A	1284	20\$:	
	073A	1285		ENBINT
	073D	1286		
05	073D	1287		RSB
	073E	1288		

```

; RESTORE SAVED FORK IPL FROM STACK

```

**YFDE**  
**Symt**

[illegible]

```
073E 1290 .SBTTL PORT ROUTINES STOP,RESUME,XON,XOFF
073E 1291 :++
073E 1292 : YF$XOFF - SEND XOFF
073E 1293 : YF$XON - SEND XON
073E 1294 : YF$STOP - STOP OUTPUT
073E 1295 : YF$ABORT - ABORT CURRENT OUTPUT
073E 1296 : YF$RESUME - RESUME STOPPED OUTPUT
073E 1297 :
073E 1298 : FUNCTIONAL DESCRIPTION:
073E 1299 :
073E 1300 : THESE ROUTINES ARE USED BY THE THE TERMINAL CLASS DRIVER TO
073E 1301 : CONTROL OUTPUT ON THE PORT
073E 1302 :
073E 1303 : INPUTS:
073E 1304 :
073E 1305 : R5 = UCB ADDRESS
073E 1306 :
073E 1307 : OUTPUTS:
073E 1308 :
073E 1309 : R5 = UCB ADDRESS
073E 1310 : --
073E 1311 :
073E 1312 : SCHEDULE XOFF OR XON TO BE SEND
073E 1313 :
073E 1314 : INPUTS:
073E 1315 :
073E 1316 : R3 - CONTAINS THE CHARACTER TO SEND AS FLOW CONTROL.
073E 1317 :
073E 1318 :
073E 1319 : To send an XON we just clear the Force XOFF bit
073E 1320 YF$XON:
073E 1321 :
073E 1322 : Forget any stored 'XOFF' character
073E 1323 : BICW #TTY$M_TANK_PREMPT,- ; RESET XOFF STATE
0100 8F AA 0742 1324 : UCBSW_TT_HOED(R5)
0108 C5 0745 1325 : SETIND
0754 1326 :
0754 1327 : Clearing this bit will make the device send an XON asap
0754 1328 :
0754 1329 : BICW #DHULCT$M_SNDOFF,DHULCT(R0)
08 A0 20 AA 0758 1330 : CMPB R3,#^X11 ; Is it XOFF ?
11 53 91 075B 1331 : BNEQ YF$PREEMPT
1A 12 05 075D 1332 : RSB
075E 1333 :
075E 1334 : To send an XOFF we just set the Force XOFF bit.
075E 1335 :
075E 1336 YF$XOFF:
075E 1337 : SETIND
13 53 91 076D 1338 : CMPB R3,#^X13 ; Is it XOFF ?
08 A0 20 AA 0770 1339 : BNEQ YF$PREEMPT ; Not XOFF, have to do it the hard way
11 53 91 0772 1340 : BISW #DHULCT$M_SNDOFF,DHULCT(R0)
1A 12 05 0776 1341 : RSB
0777 1342 :
0777 1343 : we have to send a character here (other than normal XON/XOFF),
0777 1344 : so see if the device is idle
0777 1345 :
0777 1346 YF$PREEMPT:
```

```
3B 64 A5 01 E2 0777 1347          BBSS    #UCBSV_INT,UCBSW_STS(R5),30$    ; Branch if active
OD A0 21 95 077C 1348          TSTB    DHUTBF2+1(R0)
18 077F 1349          BGEQ     10$    ; XOFFED, don't set timer
0781 1350          TIMSET    #1,R1,LOCKOUTPUT
07A2 1351          :
07A2 1352          : If this is a DHV then we send the char by single character,
07A2 1353          : else by fifo
07A2 1354          :
07A2 1355          10$:
02 A0 09 0134 C5 01 E0 07A2 1356          BBS     #UCBSV_DHU,UCBSB_DHUFLG(R5),20$
8F 8F 8000 8F A9 07A8 1357          BISW3   #^X8000,R3,DHUTXC(R0)
12 11 07AF 1358          BRB     90$
06 A0 53 90 07B1 1359          20$:
OC 11 07B1 1360          MOVB    R3,DHUTXF(R0)
07B5 1361          BRB     90$
07B7 1362          :
07B7 1363          : Transmission is in progress, save the character till
07B7 1364          : the transmission completes
07B7 1365          30$:
0100 8F A8 07B7 1366          BISW     #TTY$M_TANK_PREMPT,-    ; Set the flag
0108 C5 07BB 1367          UCBSW TT_HOCD(R5)
010A C5 53 90 07BE 1368          MOVB    R3,UCBSB_TT_PREMPT(R5) ; Save the character
07C3 1369
07C3 1370          90$:
05 07C3 1371          RSB
07C4 1372
07C4 1373          :
07C4 1374          : STOP PORT OUTPUT
07C4 1375          :
07C4 1376          YF$STOP:
50 DD 07C4 1377          PUSHL    R0
OD A0 94 07C6 1378          SETIND
07D5 1379          CLRB     DHUTBF2+1(R0)
07D8 1380          :
07D8 1381          : Note. We dont reset UCBSM_INI for the DHU,DHV in case the
07D8 1382          : device finishes transmitting
07D8 1383          :
0134 C5 04 88 07D8 1384          BISB    #UCBSM_XOFF,UCBSB_DHUFLG(R5) ; set to indicate xoff
64 A5 01 8A 07DD 1385          BICB    #UCBSM_TIM,UCBSW_STS(R5) ; Reset timer
01 01 BA 07E1 1386          POPR     #^M<R0>
05 05 07E3 1387          RSB
07E4 1388          :
07E4 1389          : ABORT ANY CURRENT PORT OUTPUT ACTIVITY
07E4 1390          :
07E4 1391          YF$ABORT:
18 64 A5 50 DD 07E4 1392          PUSHL    R0
0130 C5 01 E1 07E6 1393          BBC     #UCBSV_INT,UCBSW_STS(R5),15$ ; SKIP IF NOT BUSY.
08 A0 01 A8 07EB 1394          BISB    #TTY$M_TP_ABORT,UCBSB_TP_STAT(R5) ; REQUEST DMA ABORT
07F0 1395          SETIND
0803 1396          BISW     #DHULCT$M_ABORT,DHULCT(R0)
01 01 BA 0803 1397          15$:
05 05 0803 1398          POPR     #^M<R0>
0805 1399          RSB
0806 1400          :
0806 1401          : RESUME PREVIOUSLY STOPPED PORT OUTPUT
0806 1402          :
0806 1403          YF$RESUME:
```

```

      OF BB 0806 1404      PUSHR  #^M<R0,R1,R2,R3>
      0808 1405      SETIND
OD A0 80 BF 90 0817 1406      MOVB  #^X80,DHUTBF2+1(R0)      ; ENABLE TRANSMIT
0134 C5 04 BA 081C 1407      BICB  #UCBSM_XOFF,UCBSB_DHUFLG(R5)      ; clear to indicate xon
33 64 A5 01 E0 0821 1408      BBS  #UCBSV_INT,UCBSW_STS(R5),50$      ; Recalculate timeout
2A 0108 C5 0B E5 0826 1409      BBCC  #TTY$V_TANK_BURST,UCBSW_TT_HOLD(R5),40$      ; NO BURST IN PROGRESS
      082C 1410      ; (RESET ANYWAY. WILL BE
      082C 1411      ; SET IF NEEDED BY BURST_OUT
51 0120 C5 3C 082C 1412      MOVZWL UCBSW_TT_OUTLEN(R5),R1      ; GET NUMBER CHARACTERS
      0831 1413      TIMSET  R1,R1,LOCKOUTPUT      ; COMPUTE TIMEOUT AND
      0852 1414      ; SET INTERRUPT EXPECTED
      FBED CF 16 0852 1415      JSB  BURST_OUTPUT      ; RESTART OUTPUT
      0856 1416 40$:
      OF BA 0856 1417      POPR  #^M<R0,R1,R2,R3>
      05 0858 1418      RSB
      0859 1419
      0859 1420 50$:
      0859 1421      ;
      0859 1422      ; reset timeout for the DHU/DHV
      0859 1423      ;
      0859 1424      ; We use the number of characters that the DHU has got left to send
      0859 1425      ; plus the number in the remaining part of the buffer
      0859 1426      ; Note that the byte count may not be updated by the DHU/DHV
      0859 1427      ; so we will over estimate the timeout value
      0859 1428      ; We have to add 64 because these characters may be in the Transmit fifo
51 0040 BF 3C 0859 1429      MOVZWL #64,R1
51 51 0E A0 A0 085E 1430      ADDW  DHUTCT(R0),R1
51 0120 C5 A0 0862 1431      ADDW  UCBSW_TT_OUTLEN(R5),R1
      0867 1432      TIMSET  R1,R1,LOCKOUTPUT      ; COMPUTE TIMEOUT AND
      0888 1433      ; SET INTERRUPT EXPECTEDD
      CC 11 0888 1434      BRB  40$
      088A 1435
```



```
088A 1437 .SBTTL OUTPUT INTERRUPT SERVICE
088A 1438 :++
088A 1439 :YF$INTOUT - DHU OUTPUT INTERRUPT SERVICE
088A 1440 :
088A 1441 :FUNCTIONAL DESCRIPTION:
088A 1442 :
088A 1443 :THIS ROUTINE IS ENTERED WHEN THE DHU FINDS A LINE ENABLED
088A 1444 :AND AN EMPTY UART. THE CORRESPONDING UCB IS FOUND AND
088A 1445 :ANY OUTSTANDING PORT OUTPUT IS DONE. WHEN ALL OUTSTANDING PORT
088A 1446 :OUTPUT IS COMPLETED, THE CLASS DRIVER IS CALLED TO RETURN THE NEXT
088A 1447 :CHARACTER OR STRING TO BE OUTPUT. IF NO MORE OUTPUT IS FOUND, THEN
088A 1448 :THE LINE IS DISABLED.
088A 1449 :
088A 1450 :INPUTS:
088A 1451 :
088A 1452 :    SP(00) = ADDRESS OF THE IDB
088A 1453 :
088A 1454 :IMPLICIT INPUTS:
088A 1455 :
088A 1456 :    R0,R1,R2,R3,R4,R5 SAVED ON THE STACK.
088A 1457 :
088A 1458 :OUTPUTS:
088A 1459 :
088A 1460 :    THE INTERRUPT IS DISMISSED.
088A 1461 :
088A 1462 :--
088A 1463 YF_OUT_EXIT:
088A 1464     ADDL    #4,SP          ; EXIT OUTPUT INTERRUPT
088D 1465     MOVQ   (SP)+,R0     ; REMOVE IDB ADDRESS
0890 1466     MOVQ   (SP)+,R2     ; RESTORE REGISTERS
0893 1467     MOVQ   (SP)+,R4
0896 1468     REI
0897 1469
0897 1470 YF$INTOUT::
0897 1471
0897 1472 YF_OUT_LOOP:
0897 1473     MOVL    @ (SP),R4      ; GET THE IDB ADDRESS
089B 1474     MOVL    (R4),R0    ; GET THE CSR ADDRESS
089E 1475
089E 1476 :    GET THE LINE INFO FROM THE CSR
089E 1477 :
089E 1478
089E 1479     MOVW    (R0),R2        ; GET THE CSR VALUE
08A1 1480     BGEQ   YF_OUT_EXIT
08A3 1481     ASHL   #-2,R2,R1  ; Get the Line number
08A8 1482     BICL   #^C<15>,R1
08AF 1483     MOVL   IDB$U_CBLST(R4)[R1],R5 ; GET THE UCB ADDRESS
08B4 1484     BEQL   YF_OUT_LOOP ; IF EQL THEN DISMISS
08B6 1485
08B6 1486 :    CHECK FOR BURST OR DMA ACTIVE ON LINE
08B6 1487 :
08B6 1488
08B6 1489     SETIND   R0
08BD 1489     BITW    #DHULCT$M_ABORT, DHULCT(R0) ; CHECK TO SEE IF ABORT IS SET
08C1 1490     BEQL   5$          ; EQUAL, ABORT NOT SET
08C3 1491     BICW    #DHULCT$M_ABORT, DHULCT(R0) ; CLEAR ABORT
08C7 1492 5$: CMPB    #TTY$M_TARK_BURST@-8,- ; ONLY BURST ACTIVE?
08C9 1493     UCB$W_TT_HOCD+1(R5)
```

```

      42 13 0BCC 1494      BEQL  YF_SILO      ; YES, CONTINUE SILO OUTPUT
0100 8F B3 0BCE 1495      BITW  #TTY$M_TANK_PREMPT,- ; Preempt required ?
0108 C5      0BD2 1496
      2C 12 0BD5 1497      BNEQ  40$      ; == BRW YF_PREEMPT
      0BD7 1498 9$:
1000 8F B3 0BD7 1499      BITW  #TTY$M_TANK_DMA,- ; DMA ACTIVE?
0108 C5      0BD8 1500      BNEQ  45$      ; YES, PROCESS IT. (== BRW YF_DMA_INTERRUPT)
      26 12 0BDE 1501
      0BE0 1502
      0BE0 1503      : NO PENDING DATA - LOOK FOR NEXT CHARACTER
      0BE0 1504
64 A5 03 8A 0BE0 1505 10$: BICB  #UCB$M_TIM!UCB$M_INT,UCB$W_STS(R5); CLEAR TIMEOUT AND EXPECTED
      0BE4 1506
      0BE4 1507      : CALL CLASS DRIVER FOR MORE OUTPUT
      0BE4 1508
010C D5 16 0BE4 1509      JSB  @UCB$L_TT_GETNXT(R5) ; GET THE NEXT CHARACTER
      1F 19 0BE8 1510      BLSS  YF_START_BURST ; BURST SPECIFIED
      AB 13 0BEA 1511      BEQL  YF_OUT_LOOP ; NONE
      0BEC 1512
      0BEC 1513      : OUTPUT A CHARACTER TO THE DHU/DHV
      0BEC 1514
      0BEC 1515 20$:
0A 0134 C5 01 E0 0BEC 1516      BBS  #UCB$V_DHU,UCB$B_DHUFLG(R5),30$
      0BF2 1517
      0BF2 1518      : Single char output to DHV
      0BF2 1519
02 A0 53 8000 8F A9 0BF2 1520      BISW3 #^X8000,R3,DHUTXC(R0)
      FF9B 31 0BF9 1521      BRW  YF_OUT_LOOP
      0BFC 1522
      0BFC 1523      : Fifo output to DHU
      0BFC 1524
      0BFC 1525 30$:
06 A0 53 90 0BFC 1526      MOVB  R3,DHUTXF(R0)
      FF94 31 0900 1527 35$:
      0900 1528      BRW  YF_OUT_LOOP
      0903 1529 40$:
0089 31 0903 1530      BRW  YF_PREEMPT
      0906 1531 45$:
00A8 31 0906 1532      BRW  YF_DMA_INTERRUPT
      0909 1533
      0909 1534
```

```
0909 1536
FB36 CF 16 0909 1537 YF_START BURST:
FF87 31 0909 1538 JSB BURST_OUTPUT ; START OUTPUT SILO OR DMA
090D 1539 BRW YF_OUT_LOOP
0910 1540 ;
0910 1541 ; CONTINUE SILO OUTPUT
0910 1542 ;
0910 1543 YF_SILO:
0910 1544 ;
0910 1545 ; Note. THE DHV does not have SILO output
0910 1546 ;
0910 1547 BBC #UCBSV_DHU,UCBSB_DHUFLG(R5),5$
40 8F 06 A0 91 0916 1548 CMPB DHUTFSTRO),#64 ; ANY SILO OUTPUT IN PROGRESS ?
22 12 091B 1549 BNEQ 15$ ; YES THEN LET IT COMPLETE
26 11 091D 1550 BRB 20$ ; OTHERWISE CONTINUE SILO OUTPUT
091F 1551 ;
091F 1552 ; DHV single char mode
091F 1553 ;
091F 1554 5$:
02 A0 53 011C D5 9A 091F 1555 MOVZBL @UCBSL_TT_OUTADR(R5),R3
53 8000 8F A9 0924 1556 BISW3 #^X8000,R3,DHUTXC(R0)
011C C5 D6 092B 1557 INCL UCBSL_TT_OUTADR(R5)
0120 C5 B7 092F 1558 DECW UCBSW_TT_OUTLEN(R5)
0800 8F AA 0933 1559 BNEQ 10$ ; NOT DONE
0108 C5 07 12 0935 1560 BICW #TTYSM_TANK_BURST,- ; RESET BURST ACTIVE
FF58 31 0939 1561 UCBSW_TT_HOED(R5)
093C 1562
093C 1563 10$: BRW YF_OUT_LOOP
093F 1564
093F 1565 15$:
F6F5 CF D6 093F 1566 INCL YFSL_SIL_ERROR ; INCREMENT ERROR COUNTER
F7 11 0943 1567 BRB 10$ ; == BRW YF_OUT_LOOP
0945 1568 ;
0945 1569 ; DHU silo output
0945 1570 ;
0945 1571 20$:
51 06 A0 9A 0945 1572 MOVZBL DHUTFS(R0),R1 ; number of slots
0949 1573
52 0120 C5 3C 0949 1574 MOVZWL UCBSW_TT_OUTLEN(R5),R2 ; GET CURRENT LENGTH
53 011C C5 D0 094E 1575 MOVL UCBSL_TT_OUTADR(R5),R3 ; GET CURRENT ADDRESS
51 52 B1 0953 1576 CMPW R2,R1 ; BURST LARGER THAN SILO?
52 03 1B 0956 1577 BLEQU 50$ ; NO
52 51 9A 0958 1578 MOVZBL R1,R2 ; MAXIMUM
011C C5 52 C0 095B 1579 50$: ADDL R2,UCBSL_TT_OUTADR(R5) ; UPDATE POINTER
0120 C5 52 A2 0960 1581 SUBW R2,UCBSW_TT_OUTLEN(R5) ; AND COUNT
0800 8F AA 0965 1582 BNEQ 60$ ; NOT DONE
0108 C5 07 12 0967 1583 BICW #TTYSM_TANK_BURST,- ; RESET BURST ACTIVE
52 D5 096B 1584 UCBSW_TT_HOED(R5)
52 1A 13 096E 1585 60$: TSTL R2 ; ANY ROOM AT ALL
0970 1586 BEQL 80$ ; NO THEN EXIT
0972 1587
06 A0 08 52 E9 0972 1588 BLBC R2,70$ ; EVEN TRANSFER
83 90 0975 1589 MOVW (R3)+,DHUTXF(R0) ; OUTPUT ODD BYTE
52 D7 0979 1590 DECL R2 ; UPDATE COUNT
0F 13 097B 1591 BEQL 80$ ; DONE
097D 1592 70$:
```

```
52 52 FF 8F 78 097D 1593 ASHL #1,R2,R2 ; CONVERT TO WORD COUNT
06 A0 83 B0 0982 1594 75$: MOVW (R3)+,DHUTXF(R0)
F6 52 F5 0986 1596 DELAY ; TO RELEASE THE UNIBUS
FF08 31 0989 1597 SOBGTR R2,75$ ; LOOP TILL DONE
0108 C5 0100 8F AA 098C 1598 80$: BRW YF_OUT_LOOP
53 010A C5 9A 098F 1600 YF_PREEMPT:
09 0134 C5 01 E0 098F 1601 BICW #TTY$M_TANK_PREMPT,UCB$W_TT_HOLD(R5) ; CLEAR PREEMPT BIT
02 A0 53 8000 8F A9 0996 1602 MOVZBL UCB$B_TT_PREMPT(R5),R3 ; GET CHARACTER
04 11 0998 1603 BBS #UCB$V_DHU,UCB$B_DHUFLG(R5),10$
09A1 1604 : DHV single character
09A1 1605 BISW3 #X8000,R3,DHUTXC(R0)
09A8 1606 BRB 20$
09AA 1607 : DHU FIFO output
09AA 1608 10$:
09AA 1609 MOVW R3,DHUTXF(R0)
06 A0 53 90 09AE 1610 20$: BRW YF_OUT_LOOP
FEE6 31 09B1 1611 YF_DMA_INTERRUPT:
09B1 1612 : CHECK TO MAKE SURE NO DATA IS PENDING BEFORE ASKING FOR MORE
09B1 1613 :
09B1 1614 :
04 FEE2 CF DF 09B1 1615 PUSHAL YF_OUT_LOOP ; BUILD RETURN ADDRESS ON STACK
52 0C E1 09B5 1616 BBC #DHUCSR$V_DMAERR,R2,5$ ; CHECK FOR A DMA ERROR
F683 CF D6 09B9 1617 INCL YF$L_DMAERR_ERROR ; ERROR OCCURED INCREMENT COUNTS
06 93 09BD 1618 5$:
0130 C5 06 09BD 1619 BITB #TTY$M_TP_ALLOC!TTY$M_TP_DLLOC,- ;CHECK FOR FORKS ACTIVE
1C 12 09BF 1620 UCB$B_TP_STAT(R5) ; AND IGNORE IF SO
0130 C5 00 E0 09C2 1621 BNEQ 20$
10 09C4 1622 BBS #TTY$V_TP_ABORT,UCB$B_TP_STAT(R5),-
0C A0 95 09C9 1623 10$ ;ABORT ACTIVE DMA
12 19 09CA 1624 30$ ; ANY DMA IN PROGRESS ?
0E A0 B5 09CF 1625 TSTB DHUTBF2(R0) ; YES, then let it complete
06 13 09D2 1626 BEQL 10$ ; TEST DMA BYTE COUNT
F664 CF D6 09D4 1627 INCL YF$L_ERROR ; DMA BYTE COUNT DONE
06 11 09D8 1628 BRB 20$ ; NO THEN CONTINUE
0E A0 B4 09DA 1629 10$:
FB7D 31 09DD 1630 CLRW DHUTCT(R0) ; CLEAR DMA BYTE COUNT (ABORT WAS CLEARED)
09E0 1631 BRW DMA_CONTINUE ; OTHERWISE, CONTINUE THE DMA
09E0 1632 :
09E0 1633 : IF THIS INTERRUPT WAS THE RESULT
09E0 1634 : OF AN ABORT, THIS WILL BE HANDLED
09E0 1635 : BY DMA_CONTINUE
05 09E0 1636 20$:
09E1 1637 RSB
09E1 1638
09E1 1639
09E1 1640 30$:
F653 CF D6 09E1 1641 INCL YF$L_SIL_ERROR
SE 04 C0 09E5 1642 ADDL #4, SP ; Pop off return address
```



YFDRIVER  
V04-000

- Port Driver for DHU/DHV  
OUTPUT INTERRUPT SERVICE

J 8

16-SEP-1984 02:26:48  
5-SEP-1984 04:17:43

VAX/VMS Macro V04-00  
[TTDRVR.SRC]YFDRIVER.MAR;1

Page 38  
(1)

FEAC 31 09EB 1650 BRW YF\_OUT\_LOOP  
09EB 1651

\_S2

Pse

SADI

SDA

SGL

SOW

DIG

REA

SEE

SYS

SYS

SCO

SCO

```
.SBTTL SET SPEED, PARITY PARAMETERS
09EB 1653
09EB 1654
09EB 1655 :++
09EB 1656 : YFSSET_LINE - RESET SPEED, PARITY
09EB 1657
09EB 1658 : FUNCTIONAL DESCRIPTION:
09EB 1659
09EB 1660 : INPUTS:
09EB 1661
09EB 1662 : R5 - UCB ADDRESS
09EB 1663
09EB 1664 : OUTPUTS:
09EB 1665
09EB 1666 : R4 USED
09EB 1667 :--
09EB 1668
09EB 1669 YFSSET_LINE:
09EB 1670 PUSHF #M<R2,R3>
54 24 A5 D0 09ED 1671 MOVL UCB$C_CRB(R5),R4 ; ADDRESS CRB
54 2C B4 D0 09F1 1672 MOVL @CRB$C_INTD+VEC$L_IDB(R4),R4 ; GET THE CSR ADDRESS VIA CRB
52 08 A0 3C 09F5 1673 SETIND
0A04 1674 MOVZWL DHULCT(R0),R2 ; Fetch the line control reg
0A08 1675
0A08 1676 :
0A08 1677 : The DHU/DHV have automatic detection of received XON/XOFF and also
0A08 1678 : automatic generation of XON/XOFF options
0A08 1679
14 0122 C5 05 E1 0A08 1680 BBC #TT$V_PC_XOFAVL,UCB$W_TT_PRTCTL(R5),4$; AUTOXON XOFF AVAILABLE ON T
0A0E 1681 ; YES THEN IS
0A0E 1682
0A0E 1683 : Assume that both modes are required
0A0E 1684
52 12 AB 0A0E 1685 BISW #<DHULCT$M_OAUTO ! DHULCT$M_IAUTO>,-
0A10 1686 R2; Assume AUTOXOFF
0A11 1687
0A11 1688 : Disable detection of received XON/XOFF if not allowed
0A11 1689
03 0122 C5 06 E0 0A11 1690 BBS #TT$V_PC_XOFENA,UCB$W_TT_PRTCTL(R5),2$; AUTOXON XOFF ENABLED
52 02 AA 0A17 1691 BICW #DHULCT$M_OAUTO,R2 ; NO THEN CLEAR THE AUTOXOFF ENABLE
0A1A 1692 2$:
0A1A 1693
0A1A 1694 : Disable sending of XON/XOFF if hostsync is not set
0A1A 1695 : (The DHU/DHV can send XON/XOFF automatically if the receive fifo fills up)
0A1A 1696
03 44 A5 04 E0 0A1A 1697 BBS #TT$V_HOSTSYNC,UCB$L_DEVDEPEND(R5),4$; Host sync specified ?
52 10 AA 0A1F 1698 BICW #DHULCT$M_IAUTO,R2 ; No, then clear enable flag
0A22 1699
52 0100 BF AA 0A22 1700 4$: BICW #DHULCT$M_MODEM,R2
05 44 A5 15 E1 0A27 1701 BBC #TT$V_MODEM,UCB$L_DEVDEPEND(R5),6$
52 0100 BF AB 0A2C 1702 BISW #DHULCT$M_MODEM,R2
0A31 1703
0A31 1704 :
0A31 1705 : move updated register back into device
0A31 1706
08 A0 52 B0 0A31 1707 6$: MOVW R2,DHULCT(R0)
7E D4 0A35 1708 CLRL -(SP) ; RESET A TEMPORARY LOCATION
0A37 1709 :
```

```
0A37 1710 : SET UP LINE SPEED AND PARITY
0A37 1711 :
0A37 1712 :
00F5 C5 95 0A37 1713 TSTB UCBSW_TT_SPEED+1(R5) : RECEIVE SPEED SPECIFIED?
07 12 0A3B 1714 BNEQ 8$ : YES
00F4 C5 90 0A3D 1715 MOVB UCBSW_TT_SPEED(R5) - : NO, SO USE TRANSMITTER SPEED
00F5 C5 0A41 1716 UCBSW_TT_SPEED+1(R5)
53 00F4 C5 9A 0A44 1717 8$: MOVZBL UCBSW_TT_SPEED(R5),R3 : Get TRANSMIT SPEED
53 F637 CF43 90 0A49 1719 MOVB YF$VMS_SPEEDS[R3],R3
19 19 0A4F 1720 BLSS 10$ : Illegal speed
6E 04 0C 53 F0 0A51 1721 INSV R3,#DHULPR$V_TSPEED,#4,(SP) : SET TRANSMIT SPEED
53 00F5 C5 9A 0A56 1722 MOVZBL UCBSW_TT_SPEED+1(R5),R3
53 F625 CF43 90 0A5B 1723 MOVB YF$VMS_SPEEDS[R3],R3
07 19 0A61 1724 BLSS 10$ : Illegal speed
6E 04 08 53 F0 0A63 1725 INSV R3,#DHULPR$V_RSPEED,#4,(SP) : SET RECEIVE SPEED
27 11 0A68 1726 BRB 20$ : set current speed
0A6A 1727
0A6A 1728 10$:
0A6A 1729 : This code restores the speed to its previous value
0A6A 1730 : It is entered when an illegal speed combination is detected.
0A6A 1731
0A6A 1732
53 04 A0 B0 0A6A 1733 MOVW DHULPR(R0),R3 : get line parameters
6E 53 B0 0A6E 1734 MOVW R3,(SP) : use previous speed as new
6E 94 0A71 1735 CLRB (SP)
53 53 04 0C EF 0A73 1736 EXTZV #DHULPR$V_TSPEED,#4,R3,R3 : extract speed
00F4 C5 F618 CF43 90 0A78 1737 MOVB YF$DHU_SPEEDS[R3],UCBSW_TT_SPEED(R5); convert to VMS value
0A80 1738
53 53 04 A0 B0 0A80 1739 MOVW DHULPR(R0),R3 : get line parameters
53 53 04 08 EF 0A84 1740 EXTZV #DHULPR$V_RSPEED,#4,R3,R3 : extract speed
00F5 C5 F607 CF43 90 0A89 1741 MOVB YF$DHU_SPEEDS[R3],UCBSW_TT_SPEED+1(R5); convert to VMS value
0A91 1742
0A91 1743 : insert other parameters in the new LPR value
0A91 1744
0A91 1745 20$:
0A91 1746
53 00F8 C5 02 03 EE 0A91 1747 EXTV #UCBSV_TT_LEN,#2,UCBSB_TT_PARITY(R5),R3 : GET CHAR SIZE
6E 02 03 53 F0 0A98 1748 INSV R3,#DHULPR$V_SIZE,#2,(SP) : SET IT
53 00F8 C5 02 06 EE 0A9D 1750 EXTV #UCBSV_TT_PARTY,#2,UCBSB_TT_PARITY(R5),R3 : GET PARITY/ODD
6E 02 05 53 F0 0AA4 1751 INSV R3,#DHULPR$V_PARITY,#2,(SP)
6E 00000040 8F CC 0AA9 1752 XORL #DHULPR$M_ODD,(SP) : Correct sense
0A80 1753
53 00F8 C5 01 05 EE 0A80 1754 EXTV #UCBSV_TT_STOP,#1,UCBSB_TT_PARITY(R5),R3 : GET STOP
6E 01 07 53 F0 0AB7 1755 INSV R3,#DHULPR$V_STOP,#1,(SP)
0ABC 1756
04 A0 6E B1 0ABC 1757 CMPW (SP),DHULPR(R0) : Any modifications to be made?
04 13 0AC0 1758 BEQL 30$ : EQL, no then return
04 A0 6E F7 0AC2 1759 CVTLW (SP),DHULPR(R0) : INSERT AS LINE PARAMETER
5E 04 0C BA 0AC6 1760 ADDL #4,SP : Restore stack
05 05 0AC9 1761 POPR #*M<R2,R3> : Restore registers
0ACB 1762
0ACC 1763
0ACC 1764
0ACC 1765
0ACC 1766 YF$END: : end of driver
```

YFDRIVER  
V04-000

- Port Driver for DHU/DHV  
SET SPEED, PARITY PARAMETERS

OACC 1767 .END

M 8

16-SEP-1984 02:26:48 VAX/VMS Macro V04-00  
5-SEP-1984 04:17:43 [TTDRVR.SRC]YFDRIVER.MAR;1

Page 41  
(1)

-\$25

Symb

FOUR

GENE

GETC

GETC

GETC

GETC

GETC

GETC

GETC

GETC

GETC

GETC

GETC

GRP

HELP

HOLD

IDEN

LBR

LETT

LGIS

LIB

LIB

LIB

LIB

LIB

LIB

LIB

LIB

LIB

LIB

LIB

LIB

LIB

LIB

LIB

LIB

LIB

LIB

LIB

LIB

LIB

LIB

LIB

LIB

LIB

LIB

LIB

LIB

LIB

LIB

LIB

LIB

LIB

LIB

LIB

LIB

LIB

LIB

LIB



YFDRIVER  
Symbol table

- Port Driver for DHU/DHV

N 8

16-SEP-1984 02:26:48 VAX/VMS Macro V04-00  
5-SEP-1984 04:17:43 [TTDRVR.SRC]YFDRIVER.MAR;1

Page 42  
(1)

```

$$$
$$OP
ATS_UBA
BIT...
BUG$ UNSUPRTCPU
BURST_OUTPUT
CLASS-DDT
CLASS-DS_TRAN
CLASS-FORK
CLASS-GETNXT
CLASS-POWERFAIL
CLASS-PUTNXT
CLASS-READERROR
CLASS-SETUP_UCB
CRBSB-TT TYPE
CRBSL-INTD
CRBSL-INTD2
DC$ TERM
DDBSL-DDT
DEVSM-AVL
DEVSM-CCL
DEVSM-IDV
DEVSM-NNM
DEVSM-ODV
DEVSM-REC
DEVSM-TRM
DHUCSR
DHUCSR$C_BASE
DHUCSR$M_CLEAR
DHUCSR$M-DIGFAL
DHUCSR$M-DMAERR
DHUCSR$M-IADDR
DHUCSR$M-LINE
DHUCSR$M-RCVINT
DHUCSR$M-SNDINT
DHUCSR$M-SNDRDY
DHUCSR$S_CLEAR
DHUCSR$S-DIGFAL
DHUCSR$S-DMAERR
DHUCSR$S-IADDR
DHUCSR$S-LINE
DHUCSR$S-RCVINT
DHUCSR$S-SNDINT
DHUCSR$S-SNDRDY
DHUCSR$V_CLEAR
DHUCSR$V-DIGFAL
DHUCSR$V-DMAERR
DHUCSR$V-IADDR
DHUCSR$V-LINE
DHUCSR$V-RCVINT
DHUCSR$V-SNDINT
DHUCSR$V-SNDRDY
DHULCT
DHULCT$M-ABORT
DHULCT$M-BREAK
DHULCT$M-DTR
DHULCT$M-IAUTO

```

```

= 00000020 R 02
= 00000002
= 00000001
= 00000003
***** X 03
00000443 R 03
= 00000010
= 0000000C
= 0000001C
= 00000000
= 00000020
= 00000004
= 00000014
= 00000008
= 00000008
= 00000024
= 00000048
= 00000042
= 0000000C
= 00040000
= 00000002
= 04000000
= 00000200
= 08000000
= 00000001
= 00000004
= 00000000
= 00004040
= 00000020
= 00002000
= 00001000
= 0000000F
= 00000F00
= 00000040
= 00004000
= 00008000
= 00000001
= 00000001
= 00000001
= 00000001
= 00000004
= 00000004
= 00000001
= 00000001
= 00000001
= 00000005
= 00000000
= 0000000C
= 00000000
= 00000008
= 00000006
= 0000000E
= 0000000F
= 00000008
= 00000001
= 00000008
= 00000200
= 00000010

```

```

DHULCT$M-MAINT
DHULCT$M-MODEM
DHULCT$M-OAUTO
DHULCT$M-RCV
DHULCT$M-RTS
DHULCT$M-SNDOFF
DHULCT$S-ABORT
DHULCT$S-BREAK
DHULCT$S-DTR
DHULCT$S-IAUTO
DHULCT$S-MAINT
DHULCT$S-MODEM
DHULCT$S-OAUTO
DHULCT$S-RCV
DHULCT$S-RTS
DHULCT$S-SNDOFF
DHULCT$V-ABORT
DHULCT$V-BREAK
DHULCT$V-DTR
DHULCT$V-IAUTO
DHULCT$V-MAINT
DHULCT$V-MODEM
DHULCT$V-OAUTO
DHULCT$V-RCV
DHULCT$V-RTS
DHULCT$V-SNDOFF
DHULPR
DHULPR$M-DIAG1
DHULPR$M-DIAG2
DHULPR$M-ODD
DHULPR$M-PARITY
DHULPR$M-RSPEED
DHULPR$M-SIZE
DHULPR$M-STOP
DHULPR$M-TSPEED
DHULPR$S-DIAG1
DHULPR$S-DIAG2
DHULPR$S-ODD
DHULPR$S-PARITY
DHULPR$S-RSPEED
DHULPR$S-SIZE
DHULPR$S-STOP
DHULPR$S-TSPEED
DHULPR$V-DIAG1
DHULPR$V-DIAG2
DHULPR$V-ODD
DHULPR$V-PARITY
DHULPR$V-RSPEED
DHULPR$V-SIZE
DHULPR$V-STOP
DHULPR$V-TSPEED
DHURBF
DHURCV$M-BUF
DHURCV$M-FRAMER
DHURCV$M-LINE
DHURCV$M-OVERRUN
DHURCV$M-PARERR

```

```

= 000000C0
= 00000100
= 00000002
= 00000004
= 00001000
= 00000020
= 00000001
= 00000001
= 00000001
= 00000001
= 00000002
= 00000001
= 00000001
= 00000001
= 00000001
= 00000001
= 00000001
= 00000001
= 00000000
= 00000003
= 00000009
= 00000004
= 00000006
= 00000008
= 00000001
= 00000002
= 0000000C
= 00000005
= 00000004
= 00000002
= 00000004
= 00000040
= 00000020
= 00000F00
= 00000018
= 00000080
= 0000F000
= 00000001
= 00000001
= 00000001
= 00000001
= 00000004
= 00000002
= 00000001
= 00000002
= 00000006
= 00000005
= 00000008
= 00000003
= 00000007
= 0000000C
= 00000002
= 000000FF
= 00002000
= 00000F00
= 00004000
= 00001000

```

-\$2

Sym  
---  
PAR  
PAR  
PLI  
PLI  
PLI  
PLI  
PLI  
PLI  
PLI  
PLI  
PLI  
PLI  
PLI  
PRO  
PRO  
PRV  
PRV  
PRV  
PRV  
PRV  
PUR  
PWD  
R  
RAB  
RAN  
RAN  
RDB  
RDB  
REC  
REC  
REC  
REM  
REM  
RES  
RES  
RIG  
RMS  
SET  
SET  
SHO  
SHO  
SIG  
SS\$  
SS\$  
SS\$  
SS\$  
STR  
STR

DHURCVSM_VALID	=	00008000		
DHURCVSS_BUF	=	00000008		
DHURCVSS_FRAMER	=	00000001		
DHURCVSS_LINE	=	00000004		
DHURCVSS_OVERRUN	=	00000001		
DHURCVSS_PARERR	=	00000001		
DHURCVSS_VALID	=	00000001		
DHURCVSV_BUF	=	00000000		
DHURCVSV_FRAMER	=	0000000D		
DHURCVSV_LINE	=	00000008		
DHURCVSV_OVERRUN	=	0000000E		
DHURCVSV_PARERR	=	0000000C		
DHURCVSV_VALID	=	0000000F		
DHUSPDSC_BAUD_110	=	00000002		
DHUSPDSC_BAUD_1200	=	00000007		
DHUSPDSC_BAUD_134	=	00000003		
DHUSPDSC_BAUD_150	=	00000004		
DHUSPDSC_BAUD_1800	=	00000008		
DHUSPDSC_BAUD_19200	=	0000000E		
DHUSPDSC_BAUD_2000	=	00000009		
DHUSPDSC_BAUD_2400	=	0000000A		
DHUSPDSC_BAUD_300	=	00000005		
DHUSPDSC_BAUD_38400	=	0000000F		
DHUSPDSC_BAUD_4800	=	0000000B		
DHUSPDSC_BAUD_50	=	00000000		
DHUSPDSC_BAUD_600	=	00000006		
DHUSPDSC_BAUD_7200	=	0000000C		
DHUSPDSC_BAUD_75	=	0000C001		
DHUSPDSC_BAUD_9600	=	0000000D		
DHUSTT	=	00000007		
DHUSTTSM_CTS	=	00000008		
DHUSTTSM_DCD	=	00000010		
DHUSTTSM_DSR	=	00000080		
DHUSTTSM_RI	=	00000020		
DHUSTTSS_CTS	=	00000001		
DHUSTTSS_DCD	=	00000001		
DHUSTTSS_DSR	=	00000001		
DHUSTTSS_RI	=	00000001		
DHUSTTSV_CTS	=	00000003		
DHUSTTSV_DCD	=	00000004		
DHUSTTSV_DSR	=	00000007		
DHUSTTSV_RI	=	00000005		
DHUTBF1	=	0000000A		
DHUTBF2	=	0000000C		
DHUTCR	=	00000002		
DHUTCT	=	0000000E		
DHUTFS	=	00000006		
DHUTXC	=	00000002		
DHUTXF	=	00000006		
DMA_ALLOC		00000522	R	03
DMA_CONTINUE		0000055D	R	03
DMA_DEALLOC		000006E8	R	03
DMA_DONE		000006D4	R	03
DMA_MAP		0000061D	R	03
DMA_NOMAP		0000057D	R	03
DMA_POST		00000708	R	03
DMA_START		000004F1	R	03

Variable	Value	Mode	Address
DPTSC_LENGTH	= 00000038		
DPTSC_VERSION	= 00000004		
DPTSINITAB	= 00000038	R	02
DPTSM_NOUNLOAD	= 00000004		
DPTSREINITAB	= 000000D3	R	02
DPTSTAB	= 000000C0	R	02
DPTSW_VECTOR	= 0000001E		
DTS_DRU	= 00000047		
DTS_DHV	= 00000046		
DYN\$C_CRB	= 00000005		
DYN\$C_DDB	= 00000006		
DYN\$C_DPT	= 0000001E		
DYN\$C_ORB	= 00000049		
DYN\$C_UCB	= 00000010		
EXESGB_CPUTYPE	*****	X	03
EXESGL_ABSTIM	*****	X	03
EXESGL_TENUSEC	*****	X	03
EXESGL_UBDELAY	*****	X	03
FUNCTAB_LEN	= 00000000		
IDBSL_UCBLST	= 00000018		
INIT_CONTINUE	= 00000235	R	03
IOSM_AUTXOF_DIS	= 00004000		
IOSM_AUTXOF_ENA	= 00002000		
IOSM_LINE_OFF	= 00000200		
IOSM_LINE_ON	= 00000800		
IOSM_LOOP	= 00000080		
IOSM_UNLOOP	= 00000100		
IOCSALOUBAMAPN	*****	X	03
IOCSMNTVER	*****	X	03
IOCSRELMAPREG	*****	X	03
IOCSRETURN	*****	X	03
MMG\$GL_SPTBASE	*****	X	03
MODEM\$C_DATASET	= 00000003		
MODEM\$C_INIT	= 00000000		
ORBSB_FLAGS	= 0000000B		
ORBSL_OWNER	= 00000000		
ORBSM_PROT_16	= 00000001		
ORBSW_PROT	= 00000018		
PORT_ABORT	= 00000020		
PORT_DS_SET	= 0000000C		
PORT_FORKRET	= 00000034		
PORT_LENGTH	= 00000038		
PORT_MAINT	= 00000030		
PORT_RESUME	= 00000024		
PORT_SET_LINE	= 00000008		
PORT_STARTIO	= 00000000		
PORT_STOP	= 00000018		
PORT_VECTOR	= 00000048	R	03
PORT_XOFF	= 00000014		
PORT_XON	= 00000010		
PR\$ IPL	= 00000012		
PR\$SID_TYP780	= 00000001		
SILD_OUTPUT	= 00000469	R	03
SIZ...	= 00000001		
SS\$ NORMAL	= 00000001		
TT\$C_BAUD_110	= 00000003		
TT\$C_BAUD_1200	= 00000008		



TTSC_BAUD_134	=	00000004
TTSC_BAUD_150	=	00000005
TTSC_BAUD_1800	=	00000009
TTSC_BAUD_19200	=	00000010
TTSC_BAUD_2000	=	0000000A
TTSC_BAUD_2400	=	0000000B
TTSC_BAUD_300	=	00000006
TTSC_BAUD_4800	=	0000000D
TTSC_BAUD_600	=	00000007
TTSC_BAUD_75	=	00000000
TTSC_BAUD_9600	=	0000000F
TTSM_DS_CARRIER	=	00000020
TTSM_DS_CTS	=	00000010
TTSM_DS_RING	=	00000040
TTSV_DS_DSR	=	00000007
TTSV_HOSTSYNC	=	00000004
TTSV_MODEM	=	00000015
TTS_UNKNOWN	=	00000000
TTY\$GB_DEFSPEED		*****
TTY\$GB_PARITY		*****
TTY\$GB_RSPEED		*****
TTY\$GB_SILOTIME		*****
TTY\$GL_DEFCHAR		*****
TTY\$GL_DEFCHAR2		*****
TTY\$GL_DPT		*****
TTY\$GL_OWNUIC		*****
TTY\$GW_DEFBUF		*****
TTY\$GW_DMASIZE		*****
TTY\$GW_PROT		*****
TTY\$M_PC_DMAAVL	=	00000004
TTY\$M_PC_MAPAVL	=	00000010
TTY\$M_PC_XOFAVL	=	00000020
TTY\$M_TANK_BURST	=	00000800
TTY\$M_TANK_DMA	=	00001000
TTY\$M_TANK_PREMPT	=	00000100
TTY\$M_TP_ABORT	=	00000001
TTY\$M_TP_ALLOC	=	00000002
TTY\$M_TP_DLLOC	=	00000004
TTY\$V_PC_DMAENA	=	00000001
TTY\$V_PC_MAPAVL	=	00000004
TTY\$V_PC_NOTIME	=	00000000
TTY\$V_PC_PRMMAP	=	00000003
TTY\$V_PC_XOFAVL	=	00000005
TTY\$V_PC_XOFENA	=	00000006
TTY\$V_TANK_BURST	=	0000000B
TTY\$V_TP_ABORT	=	00000000
TTY\$V_TP_ALLOC	=	00000001
TTY\$V_TP_DLLOC	=	00000002
UBASL_MAP	=	00000800
UCB\$B_DEVCLASS	=	00000040
UCB\$B_DEVTYPE	=	00000041
UCB\$B_DHUFLG	=	00000134
UCB\$B_DIPL	=	0000005E
UCB\$B_FIPL	=	0000000B
UCB\$B_TP_STAT	=	00000130
UCB\$B_TT_DEPARI	=	000000EC
UCB\$B_TT_DETYPE	=	000000F0

X	02
X	02
X	02
X	03
X	02
X	02
X	03
X	02
X	02
X	03
X	02

UCBSB-TT-DS-RCV	=	00000124
UCBSB-TT-DS-TX	=	00000125
UCBSB-TT-MAINT	=	0000012A
UCBSB-TT-PARITY	=	000000F8
UCBSB-TT-PREMP	=	0000010A
UCBSB-TT-LENGTH	=	00000134
UCBSL-CRB	=	00000024
UCBSL-DDB	=	00000028
UCBSL-DDT	=	00000088
UCBSL-DEVCHAR	=	0000003
UCBSL-DEVCHAR2	=	0000003C
UCBSL-DEVDEPEND	=	00000044
UCBSL-DEVDEPN2	=	00000048
UCBSL-DUETIM	=	0000006C
UCBSL-TP-MAP	=	0000012C
UCBSL-TT-CLASS	=	00000114
UCBSL-TT-DECHA1	=	000000C8
UCBSL-TT-DECHAR	=	000000C4
UCBSL-TT-GETNXT	=	0000010C
UCBSL-TT-OUTADR	=	0000011C
UCBSL-TT-PORT	=	00000118
UCBSL-TT-PUTNXT	=	00000110
UCBSL-TT-RTIMOU	=	000000B4
UCBSL-TT-WBLINK	=	000000D0
UCBSL-TT-WFLINK	=	000000CC
UCBSM-DHO	=	00000002
UCBSM-INT	=	00000002
UCBSM-MAP	=	00000000
UCBSM-ONLINE	=	00000010
UCBSM-TIM	=	00000001
UCBSM-XOFF	=	00000004
UCBSM-DHU	=	00000001
UCBSM-MAP	=	00000001
UCBSM-XOFF	=	00000001
UCBSV-DHU	=	00000001
UCBSV-INT	=	00000001
UCBSV-MAP	=	00000000
UCBSV-ONLINE	=	00000004
UCBSV-POWER	=	00000005
UCBSV-TT-DSBL	=	00000007
UCBSV-TT-LEN	=	00000003
UCBSV-TT-PARTY	=	00000006
UCBSV-TT-STOP	=	00000005
UCBSV-XOFF	=	00000002
UCBSW-DEVBUFSIZ	=	00000042
UCBSW-STS	=	00000064
UCBSW-TT-DESIZE	=	000000F1
UCBSW-TT-DESPEE	=	000000E8
UCBSW-TT-HOLD	=	00000108
UCBSW-TT-OUTLEN	=	00000120
UCBSW-TT-PRTCTL	=	00000122
UCBSW-TT-SPEED	=	000000F4
UCBSW-TT-UNITBIT	=	00000106
UCBSW-UNIT	=	00000054
VECSL-ADP	=	00000014
VECSL-IDB	=	00000008
VECSL-INITIAL	=	0000000C

[illegible]

Symbol	Value	Mode	Priority
VECSL_UNITINIT	00000018		
VECSS_MAPREG	0000000F		
VECSV_MAPREG	00000000		
VECSW_MAPREG	00000010		
YFSABORT	000007E4	R	03
YFSCTRL_ERROR	00000155	R	03
YFSDDT	00000000	RG	03
YFSDELIVER	000000A4	RG	03
YFSDHU_SPEEDS	00000095	R	03
YFSDPT	00000000	RG	02
YFSDS_SET	0000033C	R	03
YFSEND	00000ACC	R	03
YFSFORK	0000071F	R	03
YFSINITIAL	000000C8	RG	03
YFSINITLINE	00000156	RG	03
YFSINTINP	0000036F	RG	03
YFSINTOUT	00000897	RG	03
YFSL_DMAXMT_ERROR	00000040	RG	03
YFSL_ERROR	0000003C	RG	03
YFSL_INACT_ERROR	00000044	RG	03
YFSL_SIL_ERROR	00000038	RG	03
YFSMAINT	0000029B	R	03
YFSNULL	00000084	R	03
YFSPREEMPT	00000777	R	03
YFSRESUME	00000806	R	03
YFSSET_LINE	000009EB	R	03
YFSSTARTIO	0000043E	RG	03
YFSSTOP	000007C4	R	03
YFSUNIT_ERROR	00000296	R	03
YFSVEC	00000048	R	03
YFSVECEND	00000080	R	03
YFSVMS_SPEEDS	00000085	R	03
YFSXOFF	0000075E	R	03
YFSXON	0000073E	R	03
YF_DMA_INTERRUPT	000009B1	R	03
YF_INITMAP	0000022E	R	03
YF_INITNULL	00000227	R	03
YF_NOMAP	00000235	R	03
YF_OUT_EXIT	0000088A	R	03
YF_OUT_LOOP	00000897	R	03
YF_PREEMPT	0000098F	R	03
YF_SILO	00000910	R	03
YF_START_BURST	00000909	R	03

! Psect synopsis !

PSECT name	Allocation	PSECT No.	Attributes
. ABS .	00000000 ( 0.)	00 ( 0.)	NOPIC USR CON ABS LCL NOSHR NOEXE NORD NOWRT NOVEC BYTE
\$AB\$\$	00000000 ( 0.)	01 ( 1.)	NOPIC USR CON ABS LCL NOSHR EXE RD WRT NOVEC BYTE
\$\$\$105_PROLOGUE	000000E8 ( 232.)	02 ( 2.)	NOPIC USR CON REL LCL NOSHR EXE RD WRT NOVEC BYTE
\$\$\$115_DRIVER	00000ACC ( 2764.)	03 ( 3.)	NOPIC USR CON REL LCL NOSHR EXE RD WRT NOVEC LONG

—\$2

[illegible]



+-----+  
! Performance indicators !  
+-----+

Phase	Page faults	CPU Time	Elapsed Time
-----	-----	-----	-----
Initialization	29	00:00:00.04	00:00:00.19
Command processing	123	00:00:00.39	00:00:01.17
Pass 1	754	00:00:23.82	00:00:27.56
Symbol table sort	0	00:00:03.37	00:00:03.47
Pass 2	296	00:00:04.93	00:00:05.45
Symbol table output	44	00:00:00.23	00:00:00.45
Psect synopsis output	2	00:00:00.01	00:00:00.01
Cross-reference output	0	00:00:00.00	00:00:00.00
Assembler run totals	1250	00:00:32.79	00:00:38.30

The working set limit was 2550 pages.  
198247 bytes (388 pages) of virtual memory were used to buffer the intermediate code.  
There were 170 pages of symbol table space allocated to hold 3101 non-local and 128 local symbols.  
1767 source lines were read in Pass 1, producing 24 object records in Pass 2.  
80 pages of virtual memory were used to define 74 macros.

+-----+  
! Macro library statistics !  
+-----+

Macro library name	Macros defined
-----	-----
_\$255\$DUA28:[SYS.OBJ]LIB.MLB;1	35
_\$255\$DUA28:[SYSLIB]STARLET.MLB;2	12
TOTALS (all libraries)	47

3572 GETS were required to define 47 macros.

There were no errors, warnings or information messages.

MACRO/LIS=LISS:YFDRIVER/OBJ=OBJ\$:YFDRIVER MSRC\$:YFDRIVER/UPDATE=(ENHS:YFDRIVER)+EXECMLS/LIB



0405 AH-BT13A-SE  
VAX/VMS V4.0

DIGITAL EQUIPMENT CORPORATION  
CONFIDENTIAL AND PROPRIETARY

